



USAGE & CARE



- Before using for the first time, hand wash all pieces in hot, soapy water and rinse thoroughly. Dry with a soft cloth.
- Dishwasher safe; however, please note that the finish may become discolored due to certain elements in detergents. **Hand washing is recommended.**
- To prevent water spotting after washing, rinse in warm water and dry immediately. **Use a non-abrasive stainless steel cleaner or a non-chlorine cleanser** and a nylon scouring pad on difficult stains. **Abrasive cleaners or metal scouring pads may mar the surface.**
- Minerals in water or starch from food can cause a white lime residue. Remove by rubbing with a sponge that has been dipped in lemon juice or vinegar. Rinse thoroughly and dry immediately.
- **Please DO NOT put in the Microwave.**
- Oven safe up to 180°C/356°F. Under high temperature, roaster surface would be discolored. This is a normal situation and does not affect the use.

#NutriChefKitchen



Questions/Concerns: jb@pyleusa.com

