

# Jet Ski Cover

MODEL: PCVJS10, PCVJS11, PCVJS12, PCVJS13, PCVJS14

**PYLE**<sup>®</sup>  
PyleUSA.com



## Installation

1. Cover any sharp points with cloth or a sponge to avoid stressing or tearing your cover.
2. Drape your cover over your personal watercraft (PWC) with the tapered end marked "FRONT" at the bow.
3. Pull your cover below the rub rail around your entire PWC.
4. Your cover includes three straps that secure your cover to your PWC (These must be used if you are transporting your PWC on a trailer). Locate a strap attached to the bottom of a triangular tension panel along the hem. Run this strap under your PWC to the corresponding buckle on the other side, clip it into that buckle and tighten as needed. Repeat with the other two straps.
5. After attaching ALL three straps adjust and tighten all the straps so that your cover is snug and even across your PWC. Roll up any extra length of strap hanging below the buckle and secure it with the rip-and-grip strap keeper at the end of the strap. This will keep the strap from flapping in the wind during trailer transport. For additional security tuck the extra strap and strap keeper under the cover.

## **⚠** WARNING

When transporting your PWC on a trailer or an open vehicle be sure to use and tighten all the straps—the cover could blow off and cause injury to others.

## **⚠** CAUTION!

When transporting your snowmobile on a trailer or an open vehicle be sure to use and tighten all the straps—the cover could blow off and cause injury to others.

## Trailer

To use your cover when transporting your PWC on a trailer you **MUST** use all the triling straps. Before driving check that all straps are tight and firmly attached, that the strap ends are secured by the strap keepers and that the access doors on the cover are zipped shut. After driving the first mile, it's a good idea to recheck your cover.

## Care and Cleaning

If your cover becomes dirty it can be cleaned with luke-warm water and a soft brush. **DO NOT USE SOAP** or Detergent as it may damage the protective coatings on your cover. Line dry.

## Storage

To avoid mildew be sure your cover is completely dry before you store it for any extended period in its attached stuff sack.