



NCBL60

Professional Home Kitchen Blender

Digital Countertop Power Pro Blender
with Pulse Blend

User Manual

IMPORTANT SAFEGUARDS AND CAUTIONARY INFORMATION
SAVE THESE INSTRUCTIONS
**FOR YOUR SAFETY, CAREFULLY READ ALL INSTRUCTIONS
BEFORE OPERATING YOUR NUTRICHEF NCBL60.**
For household use only!

IMPORTANT SAFEGUARDS

When using any electrical appliance, basic safety precautions should always be observed, including the following:

- **READ ALL INSTRUCTIONS BEFORE OPERATING YOUR BLENDER.**
- To protect against risk of electrical shock do not put cord, plug, or base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- **Avoid contacting moving parts.**
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Call our toll-free customer service number for information on examination, electrical repair, mechanical repair, or adjustment.
- The use of attachments, including canning jars, not recommended by the manufacturer may cause a risk of injury to persons.
- Do not blend hot liquids.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surface including stove.
- Keep hands and utensils away from moving blades while processing food to reduce the risk of severe injury to persons or damage to the food chopper. A scraper may be used but must be used only when the food chopper is not running.
- **Blades are sharp.** Handle carefully.
- This appliance is intended for processing small quantities of food for immediate consumption. This appliance is not intended to prepare large quantities of food at one time.
- To reduce the risk of injury, never place cutting blade on base without first putting bowl properly in place.
- Be certain cover is securely locked in place before operating appliance.
- Do not attempt to defeat the cover interlock mechanism.

- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

⚠ CAUTION:

To reduce the risk of personal injury and/or product/property damage:

- This product is intended solely for indoor, non-commercial, non-industrial use in processing liquids and foods for human consumption; do not use the product outdoors or for any other purpose.
- Always operate the product with the Blade Assembly in place.
- Do not attempt to place the Jar on the Base or remove the Jar from the base while the motor is running.
- To disconnect the product from an electrical outlet, pull directly on the plug; do not pull on the Power Cord.
- Do not put any stress on the Power Cord where it connects to the product, as the Power Cord could fray and break.
- If using an extension cord with this product, the marked electrical rating of the cord set must be at least as great as the electrical rating of the product.
- Always operate the product on a flat, level, stable surface.
- Do not allow the Power Cord to hang, such as over the edge of a table or counter, where it may be tripped over or pulled.

PRODUCT CONFIGURATION:



USING THE BLADES: The blender comes with two blades.



Cross blade: for puréeing and blending foods.



Flat Blade: for milling grains to make cereals.

USER GUIDE:

Task	Food	Feature	Cup type	Time	Operating Time
Blending	Fruit and vegetables	Cross Blade	Oversized cup	1min	60 seconds with MAX line (600g) filled with water.
	Fruit and vegetables	Cross Blade	Short cup	1min	60 seconds with MAX line (600g) filled with water.
Chopper	Meat	Cross Blade	Short cup	30s	30 seconds for 1 time about 100g
Grinder	Peanut, Beans	Cross Blade Flat Blade	Short cup	30s	30 seconds about 100g food
Smooth	Rice	Cross Blade Flat Blade	Tall cup, Short cup	30s	30 seconds for 1 time about 380g food

TROUBLESHOOTING:

1. If the product doesn't work, check the power plug if securely inserted into the power outlet and switched on, whether the pitcher is securely locked into position.
2. Do not place hot or boiling ingredients into the blender; allow to cool lower than 60 degrees centigrade before placing into the blender.
3. When using your blender for the first time, you may notice an odor coming from the motor. This is normal and will dissipate with use. Processing for a very long time will overheat the appliance and causes the unusual smell, turn the blender OFF and let it cool for 60 minutes.
4. If the blade or motor should jam while processing, you should pull out the power plug, take out the stem, and reduce the process load.

CLEANING AND MAINTENANCE

The appliance must be cleaned immediately after each use. Regular maintenance of your appliance will keep it safe and in proper operational order.

1. Turn off the appliance when not in use. Always grab by the plug to remove from outlet.
2. If you will not be using the Blender for an extended period of time, please keep the machine in a safe and dry place.
3. You can clean the accessories in water except the motor base.
4. Take off the plug before cleaning the motor base, always use a dry cloth to clean, never flush or dip in water.

Features:

- Home Kitchen Power Pro Blender System
- Powerful High-Speed Blending Motor
- Sleek, Modern Food Blender Style
- Convenient Lid Covers for Protein-Packed Gym Smoothies-to-Go
- Simple Electric Plug-in Design
- Stainless Steel Cutting Blade
- Powerful 360° Cylindrical Impact for Instant Nutrition Extraction
- Reinforced Serrated Blades Blend Ice Easily
- Stain Resistant & Easy-to-Clean
- Large Capacity Easy-Pour Containers
- BPA Free, Food Grade Construction
- Safe for Placement on Any Kitchen Table or Counter
- Perfect for Mixed Drinks, Fresh Juices, Smoothies, Milkshakes & More

What's in the Box:

- Electric Blender Base
- 600ml Tall Cup
- 300ml Short Cup
- 300ml Party Mug
- Cross Blade
- Flat Blade
- Lip Ring with handle
- Lip Ring
- (2) Solid Lid
- Food Recipe Book

Technical Specs:

- High-Powered Blender Motor: 600 Watt
- Blend Speed Settings: Up to 21,000+ RPM
- Blend Cup Capacity: 20 oz./10 oz.
- Noise Operating Level: <90dB
- Construction Material: Clear Tritan Blend Container, Engineered ABS Aluminum Housing
- Power Cable Length: 3' ft.
- Power Supply: 120V
- Total Blender Size (L x W x H): 5.9" x 6.0" x 13.8" -inches



Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com