



HIGH QUALITY/USB CHARGE

## POWER BANK User's Manual



Pyleaudio.com

Please, before using our product, read through the following information and guidelines

Thank you for choosing our product. The following is a list of specifications and a set of instructions on how to use this product. Contained within are a variety of connecting adaptors that can be used to power your iPod, iPhone, iPad, MP3 players, smart phones, bluetooth, digital camera, video camera, etc.


### Safety Instructions

- Please read the following content before using the products.  
By not following these instructions or by using incompatible products, you may end up damaging your device or this product.
- Check first if the voltage between the power bank and your device is compatible
  - Do not attempt to disassemble this product
  - Use and store this unit in temperatures between 32 degrees Fahrenheit and 113 degrees Fahrenheit.
  - Do not expose this product to any liquids while using it on or off.
  - Do not use this product near any source of heat, or else it may cause an explosion.
  - Please do not throw or shake this product.
  - Do not use this product if damaged.
  - Please do not crush or puncture the product.
  - When not in use, please charge this product every 3 months.
  - To clean this product, use a slightly moistened soft cleaning cloth. Do not use chemicals or powerful cleaners to clean this product.

### Product Series




### Charging Method



### Charging the power bank

Please use the micro cable to charge the power bank.



- 1) Use AC adaptor to charge the power bank.
- 2) Use USB connection to the computer to charge the power bank.

### Frequently Asked Questions

What do I do if my product does not charge?

- A. This product and charging adaptor or USB computer interface connection method is not correct.
- B. Incompatible voltage between devices
- C. Using the wrong input interface
- D. Adapter is defective

Why does this unit charge certain devices and not others?

- A. This product voltage is too low, please charging the power bank again.
- B. The amperage put out by this power bank is lower than what is required by your device.
- C. This product cable is defective, please contact the vendor or Pyle.

### Product features

External battery can charge iPad, iPod, iPhone and smartphones, tablet pc, etc  
Convenient, simple to use, high capacity USB charging. Easy to use .