

**PYLE**  
PyleUSA.com

**PYLE**  
PyleUSA.com



**VISIT US ONLINE:**  
Have a question?  
Need service or repair?  
Want to leave a comment?  
[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

**PYLE**

**Questions? Issues?**

We are here to help!  
Phone: (1) 718-535-1800  
Email: [support@pyleusa.com](mailto:support@pyleusa.com)



*PBMSPG180*  
**Wireless BT Boom Box Speaker System**

Wireless & Portable Stereo Speaker  
with Built-in LED Lights, TWS  
& Included Wired Microphone (500 Watt)

**USER MANUAL**

## WARNING


- DO NOT** place objects on top of the device, as objects may scratch the device.
- DO NOT** expose the device to dirty or dusty environments.
- DO NOT** insert any foreign objects into the device.
- DO NOT** expose the device to strong magnetic or electrical field.
- DO NOT** use the device in the rain.
- Please check with your Local Authority or retailer for proper disposal of electronic products.
- DO NOT** disassemble the device. Only a certified service technician should perform repair.
- The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

**Illegal operation may cause personal injury, which could be fatal and may cause damage to property.**

## Control Board Functions

### REMOTE CONTROL

- UNIT STANDBY MODE
- CHOOSE SIGNAL INPUT
- INCREASE MUSIC VOLUME
- NEXT SONG/CHANNEL
- DECREASE MENU VOLUME
- DECREASE MUSIC VOLUME
- INCREASE MENU VOLUME
- MUTE
- REPEAT
- PLAY/PAUSE KEY
- PREVIOUS SONG/CHANNEL
- MENU



- H: Music "treble" volume adjustment
- d: Music "bass" volume adjustment
- N1: Microphone volume adjustment
- EC: Microphone echo volume adjustment
- N2: Guitar volume adjustment
- LED: LED turn on/off
- OP: Microphone priority turn on/off
- U: Music master volume

## TWS FUNCTIONS

**For increase sound effect, our unit provides TWS function as follows:**


**Step-1:** Turn ON BT mode on your device and PBMSPG180.

**Step-2:** Press and hold one of control board/remote control "▶▶" button more than 3'S, and you will see "E- 5", on display, unit will start to connect the other unit automatically, then connect wireless BT on unit, now you can enjoy stereo sound, and adjusting one unit volume will affect the other unit.

### Remark:

- After connection, press and hold again one of control board/remote control "▶▶" button more than 3'S, you will hear "didi", unit's TWS dis-connection.
- TWS connection's distance is about 32.8 in. without obstacle.

## Control Board Functions



1. Press and hold to power **ON/OFF**, short press to choose input signal AUX/BT, when USB is inserted to play MP3, USB will be priority.
2. Press and hold to **STOP/PLAY** on USB/BT mode, short press function as follows:
  - H:** Music “**treble**” volume adjustment
  - d:** Music “**bass**” volume adjustment
  - N1:** Microphone volume adjustment
  - EC:** Microphone echo volume adjustment
  - N2:** Guitar volume adjustment
  - LED:** LED turn on/off
  - OP:** Microphone priority turn on/off
  - U:** Music master volume
3. 6.5MM microphone input jack
4. 6.5MM guitar input jack
5. Reset button when unit crash
6. Master volume for music and adjust number 2 function
7. Last song on USB/BT mode
8. Short press for next song on USB/BT mode, press and hold for TWS function
9. USB input jack
10. 3.5MM aux input jack
11. Charge and full charge LED indicator
12. DC charge input jack

### Troubleshooting and Warning

Fault	Possible Cause	Solution
<b>No sound</b>	1. No input sound source 2. Volume is too low	1. Use a better music signal 2. Adjust volume
<b>Distortion of sound</b>	1. Volume too high 2. Speaker may be damaged	1. Turn down the volume 2. Repair or replace it
<b>Karaoke does not work</b>	1. Microphone plug is not fully inserted. 2. Microphone switch is not on 3. Microphone volume knob is at the lowest position 4. Wireless microphone has low battery	1. Plug microphone properly into the socket 2. Turn on microphone switch 3. Adjust microphone volume properly 4. Replace battery
<b>MP3 does not play</b>	1. The song format in the U disc is incorrect 2. Improper operation has caused a process disorder 3. USB disc is disconnected	1. Transform song format into Mp3 format 2. Reboot the machine 3. Insert USB disc properly

## PBMSPG180

### Wireless BT Boom Box Speaker System

Wireless & Portable Stereo Speaker with Built-in LED Lights, TWS & Included Wired Microphone (500 Watt)

#### Features:

- True Wireless Stereo System
- High-Powered Speaker System
- Wireless & Portable BoomBox Stereo
- Wireless BT Music Streaming Ability
- Includes Wired Microphone for Karaoke Fun
- Multi-Color Flashing LED Lights
- Built-in LED Lights for Stunning Visuals
- Digital LCD Display
- Built-in Rechargeable Battery
- Aux (3.5mm) Input
- MP3 Digital Audio File Support
- Connect & Stream Audio from External Devices
- USB Flash Drive Memory Reader
- (2) 1/4" Input Jacks (for Microphone, Guitar, Instrument)
- 2.1 Channel Digital Amplifier Design
- Full Range Stereo Sound Reproduction
- Ported Enclosure for Extended Bass Response
- Perfect for the Backyard or Park Visits - Instant Party Anytime, Anywhere!

### Wireless BT Connectivity:

- Built-in Wireless BT Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices  
(iPhone, Android, Smartphones, iPad, Tablets, etc.)
- Wireless BT Version: 5.0
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32'+ ft.

### What's in the Box:

- Speaker System
- Wired Microphone
- Remote Control
- Power Adapter
- Carrying Strap

### Technical Specs:

- Rated Power: 500 Watts MAX
- Sound System: 6.5" Subwoofers + 2.5" Mid-Range Speakers x2
- Selectable LED Light Modes: On/Off
- Frequency Response: 55-20KHz
- Input Sensitivity: 300mV
- Digital Media File Compatibility: MP3, WMA (USB 2.0)
- Maximum USB Flash Drive Support: Up to 32GB
- Housing Construction Material: Engineered PP + Iron Net
- Built-in Rechargeable Battery: Li-ion 2500mAh, 7.4V
- Battery Operated Remote Control: Requires (2) x 'AAA' (Not Included)
- Power Supply: 120/240V (9V Power Adapter)
- Dimensions (L x W x H): 18.9" x 8.66" x 9.65" -inches



**WARNING:**

This products can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.