


PYLE
PyleUSA.com



PBMSQG5

Compact & Portable Bluetooth Wireless Speaker
Built-in Rechargeable Battery, MP3/USB Reader, FM Radio

KEY INSTRUCTIONS:



1. ON/OFF
2. Aux-in jack
3. Previous/Volume Down
4. Charging jack
5. Mode (Switch Bluetooth, USB disk, FM and AUX-IN state)
6. Play/Pause
7. Next/Volume Up
8. USB port

Bluetooth:

1. Turn the power button to "**ON**". The LED light will turn blue, blinks quickly and beeps twice.
2. Activate Bluetooth using a mobile phone. Search for device name "PyleUSA" then connect it. The blue LED light will blink slowly and will beep three times once successfully connected.
3. Play the music from your mobile phone and enjoy.
4. Short press **PREVIOUS** or **NEXT** button on the device or on Mobile phones to select songs you like.
5. Press **Play/Pause** button on the device or on Mobile phone to play/stop the music
6. Long press **PREVIOUS** or **NEXT** button to adjust volume up and down or you can adjust the volume using your mobile phones.

Play Music from USB disk

1. Turn the Power button to "**ON**".
2. Insert **USB** flash disk into slot, the music stored will be played automatically and the blue **LED** light will blink slowly.
3. Under playing mode, short press **Previous or Next** button to select the songs you like, long press to adjust the volume.
4. Press **PLAY/PAUSE** to play or pause.
5. Please turn the **Power** button to "**OFF**" when not in use.

Remark: Under Bluetooth playing mode, inserting **USB** will disconnect the Bluetooth and switch the playing from USB. You can press the **MODE** button to switch to Bluetooth mode again.

FM Radio:

1. Under **FM** radio state, the audio cable provided treat as antenna.
Please insert the audio cable to get the best **FM** signal before using.
2. Turn the power button to "**ON**", press the "**MODE**" button to switch to **FM** radio state.
3. Under playing mode, short press "**Play/Pause**" button to auto search the **FM** Channel and store it automatically.
4. Press **Previous or NEXT** button to change the stored **FM** channel.

AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device's "**Line Out**" to the "**Aux In**" of this devices. Then press the "**MODE**" button to switch to **AUX-IN** state. Enjoy...

When using an external device, all functions will be controlled by the external devise except the "**Play/Pause**" button.

Remarks:

1. Press the **MODE** button to switch different modes, the order is Bluetooth, USB disk, Micro SD card, FM radio and AUX-IN.
2. Turn the power button to "**Off**" to cut off the power supply when not in use.

How to charge:

1. Power off the unit, put the provided charger cable into the charge slot of the unit, connect the other end to a PC or in a charger with DC5V output (not included), the red light charging indicator will be lit.
2. Charging time should be 3-5 hours. When charging is full, the indicator light will switch off.
3. In order to prolong the life of battery, please do not charge more than 8 hours.

Features:

- 2-in-1 Speaker + Radio
- Compact, Portable & High-Powered
- Wireless Hi-Fi Active Stereo System
- Bluetooth Music Streaming Ability
- Built-in Rechargeable Battery
- Digital Sound Amplifier
- FM Radio with Auto-Tuning
- USB Flash Drive Reader
- MP3 Digital Audio File Compatibility
- Aux (3.5mm) Input Jack
- Ability to Connect External Devices
- Side Panel Button Control Center
- Full Range Stereo Sound Reproduction
- Convenient Carry Handle

Bluetooth Connectivity:

- Instantly Stream Music from Your Devices
- Works with All Your Favorite Bluetooth Devices (iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)
- Bluetooth Version: 4.2, A2DP
- Bluetooth Network Name: 'PyleUSA'
- Wireless Range: Over 30'+ Feet

What's in the Box:

- Wireless Tube Speaker
- USB Charging Cable
- Audio Connection Cable

Technical Specs:

- MAX Power Output: 100 Watt
- Sound System: 1.0" Full Range Stereo
- Impedance: 4 Ohm
- Signal/Noise Ratio: >50dB
- Frequency Response: 100-16kHz
- Housing Construction Material: Engineered ABS
- Digital Audio File Compatibility: MP3, WMA
- Maximum USB Flash Support: 32GB
- Rechargeable Battery: 3.7V Li-iOn, 1500mAh
- Power: DC, 5V/1A
- Dimensions (L x W x H): 10.4" x 3.6" x 3.9" –inches
- Sold as: Unit

PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE