


**PYLE**  
PyleUSA.com



## *PBMSQG9*

Compact & Portable Bluetooth Wireless Speaker  
Built-in Rechargeable Battery,  
MP3/USB/Micro SD Readers, FM Radio

## KEY INSTRUCTIONS:



1. Aux-in jack
2. Charging Jack
3. ON/OFF
4. Micro SD slot
5. USB Port
6. Play/Pause
7. Previous/Volume Down
8. EQ
9. Next/Volume Up
10. Mode (Switch Bluetooth,USB disk,Micro SD, FM and AUX-IN state)

## **Bluetooth:**

1. Turn the power button to “**ON**”. The LED light will turn blue, blinks quickly and beeps twice.
2. Activate Bluetooth using a mobile phone. Search for device name “PyleUSA” then connect it. The blue LED light will blink slowly and will beep three times once successfully connected.
3. Play the music from your mobile phone and enjoy.
4. Short press **PREVIOUS** or **NEXT** button on the device or on Mobile phones to select songs you like.
5. Press **Play/Pause** button on the device or on Mobile phone to play/stop the music
6. Long press **PREVIOUS** or **NEXT** button to adjust volume up and down or you can adjust the volume using your mobile phones.

## **Play Music from USB disk & Micro SD card**

1. Turn the **Power** button to “**ON**”. Insert USB flash disk or Micro SD card into the slot, the music stored will be played automatically and the blue LED light will blink slowly.
2. Under playing mode, short press **Previous** or **Next** button to select songs that you like, long press to adjust the volume.
3. Press **PLAY/PAUSE** to play or pause.
4. Please turn the Power button to “**OFF**” when not in use.

**Remark:** Under Bluetooth playing mode, inserting USB or Micro SD card will disconnect the Bluetooth and switch the playing from USB or Micro SD card. You can press the **MODE** button to switch to Bluetooth mode again.

### **FM Radio:**

1. Under **FM** radio state, the audio cable provided treat as antenna.  
Please insert the audio cable to get the best **FM** signal before using.
2. Turn the power button to "**ON**", press the "**MODE**" button to switch to **FM** radio state.
3. Under playing mode, short press "**Play/Pause**" button to auto search the **FM** Channel and store it automatically.
4. Press **Previous or NEXT** button to change the stored **FM** channel.

### **AUX-IN:**

For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device's "**Line Out**" to the "**Aux In**" of this devices. Then press the "**MODE**" button to switch to **AUX-IN** state. Enjoy...

When using an external device, all functions will be controlled by the external devise except the "**Play/Pause**" button.

### **Remarks:**

1. Press the **MODE** button to switch different modes, the order is Bluetooth, USB disk, Micro SD card, FM radio and AUX-IN.
2. Turn the power button to "**Off**" to cut off the power supply when not in use.

### **How to charge:**

1. Power off the unit, put the provided charger cable into the charge slot of the unit, connect the other end to a PC or in a charger with DC5V output (not included), the red light charging indicator will be lit.
2. Charging time should be 3-5 hours. When charging is full, the indicator light will switch off.
3. In order to prolong the life of battery, please do not charge more than 8 hours.

## **Features:**

- 2-in-1 Speaker + Radio
- Compact, Portable & High-Powered
- Wireless Hi-Fi Active Stereo System
- Bluetooth Music Streaming Ability
- Built-in Rechargeable Battery
- Digital Sound Amplifier
- FM Radio with Auto-Tuning
- USB Flash Drive Reader & Micro SD Memory Card Reader
- MP3 Digital Audio File Compatibility
- Aux (3.5mm) Input Jack
- Ability to Connect External Devices
- Side Panel Button Control Center
- Full Range Stereo Sound Reproduction
- Convenient Carry Handle

## **Bluetooth Connectivity:**

- Instantly Stream Music from Your Devices
- Works with All Your Favorite Bluetooth Devices (iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)
- Bluetooth Version: 4.2, A2DP
- Bluetooth Network Name: 'PyleUSA'
- Wireless Range: Over 30'+ Feet

## **What's in the Box:**

- Wireless Tube Speaker
- USB Charging Cable
- Audio Connection Cable

## **Technical Specs:**

- MAX Power Output: 150 Watt
- Sound System: 1.1" Full Range Stereo
- Impedance: 4 Ohm
- Signal/Noise Ratio: >60dB
- Frequency Response: 100-16kHz
- Housing Construction Material: Engineered ABS
- Digital Audio File Compatibility: MP3, WMA
- Maximum USB Flash/Micro SD Card Support: Up to 32GB
- Rechargeable Battery: 3.7V Li-iOn, 1500mAh
- Power: DC, 5V/1A
- Dimensions (L x W x H): 11.2" x 4.5" x 4.7" –inches
- Sold as: Unit

# PYLE

PyleUSA.com



**VISIT US ONLINE:**

*Have a question?*

*Need service or repair?*

*Want to leave a comment?*

[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

PYLE