

PYLE

PyleUSA.com



PBTNC50

Bluetooth Active Noise
Cancellation Headphone

USER MANUAL

CONTENTS

Bluetooth Connection 01~03

Basic Operation 04~05


Ports Description 06

Specifications 07

Simple Troubleshooting 08

Safety Notice 09


BLUETOOTH CONNECTION



Step1 Power on

Press for 2 seconds until red and blue indicator flashes alternatively, then enter the setting and switch on the Bluetooth in cell phone


1



Step2 Choose the device

Find the PyleUSA from the Bluetooth name list in the phone

2



Step3 Connection finish

If PyleUSA shows connected, the blue indicator will flash which means the connection successful. You can now start to play music.

3

PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?


Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE

BASIC OPERATION




1. Power/Multi-function button

- Short press for pause/play
- When a call is coming, short press to answer
- During call conversation, short press to hang off
- When a call is coming, double click to refuse the call

2. 3. Volume control buttons

- Short press 2 to turn up and long press to next track.
- Short press 3 to turn down and long press to previous track.
- Press and hold 2 & 3 together for 2 seconds to disconnect the current pairing (under Bluetooth connection mode).
- Press and hold 2 & 3 together for 5 seconds to default setting (under Bluetooth pairing mode).

4




Noise cancellation function

- Click 4 for NC on and indicator is green
- Click 4 for NC off and indicator is off

5

PORTS DESCRIPTION



Charging LED Indicators:

- During charging, red LED is ON
- When charging is finished, green LED is on
- When battery is low, red LED flashes slowly

6

PRODUCT SPECIFICATIONS

Product name	Bluetooth Active Noise Cancellation Headphone
Model	PBTNC50
Battery capacity	500mAh
Phone call talking time	NC ON: 15~18Hs
	NC OFF: 26 ~ 29Hs
Music play time	NC ON: 12 ~ 14Hs
	NC OFF: 18 ~ 23Hs
Charging time	2~3Hs
Battery Capacity	500mAh
Battery voltage	3.7V
Charging current	5V/400mAh
Dimensions	80 x 171.5 x 188mm
Weight	222g

7

SIMPLE TROUBLESHOOTING

When you meet below problems please refer to below instructions to solve, if the problems can't be solved please contact with the local distributors. Don't fix by yourself. Avoid electric shock or enlarge the trouble scope.

1. What if no sound from the headphone?
 - To check if it's connected and power on again.
 - To check if the Line in status.
2. What if the distortion happens when the volume is max.
 - Check if the audio cable is not loose and make sure it is connected properly.
 - Check if the audio cable is not loose and make sure it is connected

8

SAFETY NOTICE

PLEASE READ ALL INFORMATION AND FOLLOW INSTRUCTIONS CAREFULLY

Any sharp cutting edge, non-smooth surface, metal accessories and package will cause harm injury and bleeding, please be careful during use. Make sure to keep them out of reach of children.

Please don't modify, fix or disassemble this product. Inappropriate handling may cause short-circuit, damage or fire. We will not accept device for repair if disassembled by users.

Please don't clean the speaker's surface by detergent and any liquid, use only dry cloth. Inappropriate adjustment of the volume (such as frequent adjustment) will affect the sound quality or may cause damage. DO NOT drop, clash or crack or use on dangerous environment (such as lab) that may cause interference.

If anything abnormal happens please stop immediately. It may cause explosion under open fire and high temperature environment.

9