

PONTOON COVER

MODEL: PCVHP440

PYLE[®]
PyleUSA.com



⚠ CAUTION!

If your boat is new, use of this product is not recommended within the first four weeks of ownership of the boat. Some compounds used in new boats can release gases that will cause the dyes in boat covers to transfer to the boat, potentially staining the boat or its components. Boat covers can be used safely after this introductory period.

Installation

1. Cover any sharp points or corners with a piece of cloth to avoid stressing or tearing your boat cover when it is stretched across your boat.
2. Drape the boat cover over your boat, positioning the adjustable end at the stern.
3. Pull the boat cover down below the rub rail around the entire boat.
4. Tie one end of the supplied rope to a front D-ring sewn into the bottom hem of the corner. Pull or toss the rope under the boat to the corresponding D-ring on the opposite side. Allowing enough rope to make another knot, cut off the rope. Tie off the rope into the D-ring. Repeat with remaining D-rings.
5. Carefully singe the ends of the rope with a match or lighter to prevent fraying.
6. At the stern, use the rope to lace the adjustable transom flap over the adjustable side flaps and secure. Use the bungee cord to gather excess material.
7. Adjust and tighten as necessary for your particular boat.

Care

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes. Be sure your cover is dry before storing it. If you store your cover when it's wet it can be damaged by mildew. This cover is designed for use while storing your boat. Do not use it for trailer travel or for transportation.