

PYLE
PyleUSA.com



PKBRD37RD

Digital Musical Karaoke Keyboard

Portable Electronic Piano Keyboard
with Built-in Rechargeable Battery
and Wired Microphone, Red (37 Keys)

USER GUIDE


Please read this manual thoroughly prior to using the product in order to benefit fully from all features.

IMPORTANT SAFETY PRECAUTIONS

1. Please only use the power adaptor included in the product.
This unit may use a mobile phone adaptor with specification:
INPUT: 100-240V- 50/60Hz
OUTPUT: DC 5V, electricity should be 1000mA or above. The adaptor to be used with this product should be regularly examined for potential hazard, such as damage to the cable or cord, plug, enclosure of other parts.
Do not use the damaged products to avoid accidents.
2. The **WHITE** power **ON/OFF** button is also the charging indicator. The button will light up in red color when the piano is charging. After the Li-ion battery is fully charged, the red light will turn off. When the piano powered is ON, the button will light up in blue.
3. Please charge the piano every two months when it is not in use, in order to keep the performance and service life of the built-in Li-ion battery.
4. This product must be charged by adults.
5. The Li-ion battery is fixed inside the toy, it is strictly forbidden to be removed or put into the fire or near the high-temperature environment as it will cause explosion danger!
6. This product includes a USB cable. If you will use different USB cables, please carefully check if there's any damage to it. The mobile phone original adaptor is recommended to use with this product. An inferior USB cable and adaptor will bring noise and another potential hazard when you play this keyboard.
7. This product is not suitable for children under 3 years old.
8. Do not play the music aloud for a long time. Loud music may damage hearing.
9. **Do not place this product in below locations; otherwise it may cause fire or electric shock.**
 - Humid or dusty place
 - Kitchen or place that have lamp black
 - Near air conditioner, electric blanket, exposed under the sunlight or any other place would warm this keyboard up.
10. Do not put this product near TV, Radio or beside other electronic product which may cause audio or video receiving interference.
11. Unplug the adaptor before cleaning this product or when you are not using it for a long time.


Illustration

1. Power on/off/Charging Indicator
2. Volume control knob
3. OKON
4. Tone
5. Rhythm
6. Demo all/ Demo select
7. Stop
8. Audio input jack
9. Microphone jack
10. Headphone jack
11. DC 5V jack



POWER SUPPLY

DC Adaptor: Use DC adaptor with USB connector with voltage output DC 5V, electricity should be 1000mA or above. It may cause malfunction if you use another voltage adaptor.



TURN ON FOR PLAYING

Press the power **ON/OFF** button, blue light will light up in the button. Play any white or black keys, if there's a piano rings up, the keyboard works.

HOW TO PLAY

1. **Volume Control:** Turn this knob to raise or lower the master volume.
2. **Tone:** There're 4 tones as below. The piano setting tone is piano. Press **TONE** one time to play piano tone. Press **TONE** again to play the next tone: vibraphone. Press **TONE** the third time to play the next tone and so on.
 1. PIANO
 2. VIBRAPHONE
 3. SAXOPHONE
 4. MUSIC BOX

3. **Rhythm:** This Keyboard provides 4 rhythms. Press **RHYTHM** once to initiate the Disco rhythm. Press **RHYTHM** again to initiate the next rhythm: blues.
1. DISCO
 2. BLUES
 3. MARCH
 4. WALTZ
4. **ALL/SEL:** Press this button one time, it will enter the demo all mode and play the demos in sequence. Press this button twice, you can select the demo. There're totally 10 demos list as below:

No.	Name of Demo
1	Say Hello
2	Happy Birthday
3	Row, Row, Row Your Boat
4	Turkey March
5	Little Star
6	Scherzo
7	Old MacDonald Had a Farm
8	Les Preniers Sourires de Vanessa
9	Minuet
10	The Happy Farmer

5. **OKON (One key for one note):** Under this mode, you can press any black or white keys to play background music from the demos. Press **ALL/SEL** to select the demo first and then press **OKON** to play. Listen to the demo and get familiar with the rhythm and song, then practice.
6. **Stop:** Under the **RHYTHM, ALL/SEL** mode, press **STOP** to exit.
7. **Belt:** The belt can be installed on the screw at the bottom of the piano to carry and play the piano.

Operation notice:

1. This product should not be placed near the electric appliance, such as radio, television, tuner to avoid interference when receiving audio or video signals.
2. Use the nearest power socket in order to unplug the adaptor immediately when malfunctioning.
3. Unplug the adaptor when it is not in use.
4. The unit contains voltage carrying parts. Therefore DO NOT open the housing.

Features:

- 2-in-1 Karaoke Keyboard: Play & Sing-Along!
- Includes Wired Handheld Microphone
- Compact & Portable Musical Piano
- Simple Electronic Plug-in Operation
- Portable Piano, Built-in Rechargeable Battery
- Built-in Full Range Stereo Speaker
- Connect & Stream Audio from External Devices
- Multiple Preset Selectable Keyboard Sound, Tone & Rhythm Styles
- OKON Mode: Easy to Play the Preset Demo Song by Any Key
- Adjustable Volume Control
- Headphone Jack
- Light and Compact to Hang on the Shoulder Like a Guitar
- Perfect for Home Theater Living Room Performances
- Fun for Kids of All Ages: Children & Adults

What's in the Box:

- Portable Piano Keyboard
- Wired Microphone (stored in the polyfoam inside the gift box)
- USB Charger Power Cable
- Audio Cable
- Belt
- UL Adapter

Technical Specs:

- (37) Keyboard Keys
- (4) Preset Selectable Tones
- (4) Preset Selectable Audio Rhythms
- Belt: Black PP Webbing
- Audio Interface: Aux (3.5mm) Input Jack / Mic Input
- Max Sound Level: Up to 86 dB
- USB/Power Cable Length: 3.28' ft.
- Construction Material: Engineered ABS
- Built-in Rechargeable Battery: 3.7V Li-ion
- Power Supply: 110/240V (DC 5V)
- Power Adapter: DC-5V/1000mA
- Piano Dimensions (L x W x H): 22.04" x 4.37" x 1.57" -inches

California Prop 65 Warning



WARNING:

This product contains Butyl benzyl phthalate (BBP) which is known to the state of California to cause cancer birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov



PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE

Questions? Comments?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com

