

nutrichef
by PYLE



PKJCR305


Electric Juice Press

Orange Juicer Citrus Squeezer

USER MANUAL

DESCRIPTION

1. Press lid
2. Cone
3. Filter
4. Juice tray
5. Body
6. Helpful handle



SAFETY ADVICE AND CAUTIONS

- Read these instructions carefully before switching **ON** the appliance and keep them for future reference. Failure to follow and observe these instructions could lead to an accident.
- Clean all the parts of the product that will be in contact with food, as indicated in the cleaning section before use.

ELECTRIC SAFETY

- Do not use the appliance if the cable or plug is damaged.
- Ensure that the voltage indicated on the nameplate matches the mains voltage before plugging in the appliance.
- The appliance's plug must fit into the mains socket properly. Do not alter the plug. Do not use plug adaptors.
- Do not use or store the appliance outdoors.
- Do not use the appliance if it has fallen on the floor, if there are visible signs of damage or if it has a leak.

- Do not force the electrical connection wire. Never use the electric wire to lift up, carry or unplug the appliance.
- Ensure that the electric cable does not get trapped or tangled.
- Check the state of the electric cable. Damaged or knotted cables increase the risk of electric shock.
- Do not touch the plug with wet hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

USE AND CARE

1. Fully unroll the appliance's power cable before each use.
2. Do not turn the appliance over while it is in use or connected to the mains.
3. Disconnect the appliance from the mains when not in use and before undertaking any cleaning task.
4. This appliance is for household use only, not professional or industrial use.
5. This appliance is not a toy. Children should be supervised to ensure that they do not play with the appliance.
6. This appliance is intended for adult use. Ensure that this product is not used by the disabled, children or people unused to its handling.
7. This appliance should be stored out of reach of children and /or the disabled.
8. Do not store the appliance in a vertical position.
9. Store the appliance in a dry place, free from dust and out of direct sunlight.
10. Never leave the appliance unattended while in use.
11. Any misuse or failure to follow the instructions for use renders the guarantee and the manufacturer's liability null and void.

INSTRUCTIONS FOR USE

1. Unroll the cord completely before plugging in.
2. Connect the appliance to the mains.
3. Cut the citrus fruit/s to be squeezed in half.
4. Place the glass at the appliance's juice exit.
5. Turn **ON** the appliance by pushing down on the piece of citrus fruit, once it has been placed on the juicing cone.
6. To stop the appliance, simply stop applying pressure to the cone.
7. Remove both the cone and the filter to empty the jug.
8. Pour juice out of the jug and into glasses to serve directly.
9. If you're going to process a large quantity of fruit, you must periodically clean the filter and remove the remains of the pulp.

CLEANING

- Unplug the appliance from the mains and let it cool before starting any cleaning.
- Except for the power unit and the mains connection, all the parts can be cleaned with detergent and water or in washing up liquid. Rinse thoroughly to remove all traces of detergent.
- Clean the equipment with a damp cloth with a few drops of washing-up liquid and then dry.
- Do not use solvents, or products with an acid or base pH such as bleach, or abrasive products, for cleaning the appliance.
- Do not submerge the appliance in water or any other liquid, or place it under a running tap.
- It is advisable to clean the appliance regularly and remove any food remains.
- **The following parts can be cleaned in the dishwasher:**
Protective cover, Cone, Filter, Jug.

PKJCR305

Electric Juice Press - Orange Juicer Citrus Squeezer

Features:

- Fill Your Glass with Freshly Squeezed Juice!
- Automatic Spiral Fruit Juicer
- Simple Electric Plug-in Operation
- Used for Oranges, Lemons, Limes, Pomegranates, Grapefruits
- Convenient Pressing Handle
- Ridged Auger Cone for Maximum Juice Extraction
- Juices Quickly & Flows Through the Spout Tip
- Integrated Filter Catches Large Pulp & Seeds
- Detachable Parts for Easy Cleaning
- Sleek Stainless Steel & Stain-Resistant Housing
- Convenient Kitchen Table & Countertop Design

Technical Specs:

- High-Powered Juicing Motor: 160 Watt
- Construction Material: Stainless Steel, Engineered ABS
- Power Cable Length: 2.8' ft.
- Power Supply: 120V
- Dimensions (L x W x H): 10.2" x 7.08" x 11.14" -inches
- Sold as: 1

nutrichef

by **PYLE**



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE