

STAINLESS STEEL WATER BOILER



PKWK23GD & PKWK24SR

QUICK GUIDE

OPEN

Remove the cover in the opposite direction.

FILLING

- Open the cover and fill water into the jug.
- Do not fill it under the **MIN** level.
- Do not fill it over the **MAX** level.
- Do not forget to close the lid firmly after filling with water.

ON

- Connect the power connection to a wall outlet, then the "**Heating**" light will turn on.

Warning: Do not open the lid while the water is boiling. There's a potential danger of burns.

KEEP WARM

- When the water boils, the "**Heating**" light turns off, and the "**Keep Warm**" light turn on, the water temperature keeps warm at 185° fahrenheit.
- The kettle can be turned off manually by removing the kettle from the base at any time.

POUR WATER

- Press the **Serving Spout** button to pour water, the water stops when the button is released.