

# User's Manual

[www.pyleaudio.com](http://www.pyleaudio.com)



**PLBSBT55**


# PEDALSOUND





*Portable Bluetooth Bicycle Sport Speaker W/  
Flashlight & Power Bank Functionality*

### Specifications

- 2-in-1 Bluetooth Flashlight Speaker
- Stream Music and Enjoy Hands-Free Calls
- Waterproof Marine Grade Rating IPX4
- Built-In Microphone for Call Answering
- (4) Flashlight Modes: Dim, Bright, Slow Flash, Strobe Flash
- Power Bank Device Charging Function
- Charge Your Device by Connecting to the Pedal Sound
- Rechargeable Lithium Battery: 2300mah
- 10 Hour Battery Life
- CSR Bluetooth V2.1+ EDR
- Includes USB Charging Cable, Bicycle and Auto Visor Mounts
- Portable and Lightweight
- Bright 3W LED Light
- S/N: 82dB
- Distortion: 0.1%
- Product Size: 1.5" X 6.1"
- Frequency Response: 250HZ—20KHZ
- Net Weight: 4.7 Oz


### Function Indication








1. Lamp Base: opens to reveal USB charging port
2. Built-in Microphone
3.  Flashlight/Power Bank Button
4.  Volume Up+/Previous Song
5.  Volume Down -/ Next Song
6.  Multifunction Button: Power On&Off/ Bluetooth Pair/Play/Pause/Microphone
7. Speaker Head

## Operation



### Connecting to Bluetooth Devices

- Hold  for about 7 seconds, until the LED Indicator flashes red and blue alternately. Now its ready for pairing.
- Turn on the Bluetooth of your smart phone, and then you will see the Bluetooth named "Pyle Bike" in the list of pair-able Bluetooth devices.
- Connect it. You may be requested for a password, if so, enter **1234**.


### Note:

- Hold  to terminate the Bluetooth connection.
- When playing music, press button  /  to switch to the previous song/next song; and holding these buttons will increase/decrease volume
- When playing music, press  to stop the music, and press again  to re-start the music.



### Answer/Reject Calls

- **To answer a call:** press the button  to answer the call. And then press again to finish the call.
- **To refuse a call:** hold the button  for about 3 seconds to refuse the call.

### How to Use the Flashlight

- Press the button  to switch between the flashlight modes: Dim, Bright, Slow Flash, Strobe Flash

### How to Use the Power Bank Function

- Remove the lamp base and hold the button , now the LED indicator will light green, then you can connect your device to the USB port with the matching charging cable. You can now charge your device.
- To end the power bank function, press the button  until the green indicator is off.

### How to Charge the Device

- Remove the lamp base.
- Connect the USB interface to adaptor or PC.
- While the Pyle Sound is charging, the LED indicator will be in red; and the light will turn off once fully charged.

**What's in the Box**

- Bluetooth Speaker Torch, USB Charging Cable, User Manual, Bracket (For bicycle), Bracket (For car)

**Reminders**

- Turn off this speaker when it is not in using,
- Keep away from sharp objects.
- Do not place near heat or microwave ovens.
- Keep away from liquids.
- Store this speaker at ventilated and dry place.
- Keep this speaker with a clean, damp cloth.
- Only clean this speaker when its powered OFF.

**WARNING! IMPORTANT INSTRUCTIONS FOR THIS PRODUCT**

Please read and follow the directions for operations in this user manual for proper use.

Do not place near liquids

Do not allow the item to soak or submerge in water

Avoid dropping and physical damages or strong impacts to this product.

Do not disassemble, repair or modify this product by yourself.

Avoid leaving the unit in direct sunlight or exposure to heat.

This product is not a toy, keep away from the children.

This product contains recyclable lithium battery; please dispose of properly if necessary.



**PYLE<sup>®</sup>**  
**SPORTS**

**IMPORTANT: Pack carefully in original package if possible. We are not responsible for damage incurred in returning items for repair. A letter stating your exact street address, daytime phone number, and the problem you are experiencing should be included. You must also enclose a copy of the original receipt as proof of date of purchase**

Brooklyn, NY 11204  
(718)535-1800  
Monday Through Thursday. 9AM to 5PM  
Friday 9AM to 1PM Eastern.

**PEDALSOUND**  
PEDALSOUND

Visit Us @ [pyleaudio.com](http://pyleaudio.com)

Like Us On:   