

**Universal Laptop & DJ Equipment**

	Secondary Device Plate		Screw Knobs
	Laptop Holding Arms		Support Pole Extension
	Leg Stands		Screws
	Leg Base Plates		Washers
	Support Poles		


## Assembly:

	<p>Fasten the leg stands to the leg base plates.</p> <p>Use (2) screws and (2) washers per assembly and tighten securely.</p> <p>The leg base plates have pre-drilled holes for you to insert the leg stands towards the edge of the metal supports.</p>
	<p>The secondary device plate is adjustable so you can use the tray for different sized equipment.</p> <p>*Leave the tightening knobs loose until the final steps of assembly. Once the unit is fully assembled, you can securely tighten.</p>
	<p>The assembled leg stand and leg base plates then connect to the laptop holding arms. Use one of the screw knobs and support poles to fasten the laptop holding arm.</p> <p>The screw knob fastens to the outside of the laptop holding arm, while the support pole stretches toward the other accommodating leg stand / leg base plate assembly.</p> <p>*Do not tighten the screw knob to the support pole tightly, as you will need to slide in the secondary device plate.</p>
	<p>Use the optional included support pole extensions, if you decide to extend the length of your secondary device plate. The support pole extensions screw into the end of the support poles.</p>



While placing your support pole between the assembled stand legs, use your screw knobs on both ends to join the assembly together. The screw knobs fasten to the outside of the laptop holding arms, while the support pole lies in-between the two holding arm assemblies.

\*Do not tighten the screw knobs to the inner support pole tightly, as you will need to slide in the secondary device plate.



The secondary device plate slides **into** the assembled stand legs and slide **onto** the screw knobs.

\*Since you did not tighten the screw knobs completely, the notch groove in the secondary device plate allows it to slide in between the screw knob and stand leg.

Once you correctly position the secondary device plate on both ends (**into the leg stands & onto the screw knobs**) you can tighten the screw knobs for secure placement.



The next support pole acts as further support for mounting your devices on the laptop stand.

\*This additional support pole is preferably mounted at the highest vertical position of the leg stand assembly.

The screw knobs fasten to the outside of the laptop holding arms, while the support pole lies in-between.

\*Be sure to tighten accordingly, and use the other support pole extension, if you used the first support pole extension on the support pole used to mount the secondary device plate.