

PMP31BL - PMP32GR - PMP33SL - PMP34PK



PYLE
PyleUSA.com


Compact Megaphone Speaker

Compact Megaphone Speaker with Siren Alarm Mode

This user manual contains important information for safe operation and optimal megaphone performance. Please carefully read and follow safety notes and instructions. Save this manual for future reference. Make sure that it is available to all persons using this device.

OPERATING INSTRUCTIONS

- Open the back cover by pressing down on the **'Open'** Button
- Insert 4 x UM-1 Batteries then close back cover until locks into position. Now, your megaphone is ready for operation.
- To activate the megaphone, press the **'ON/OFF'** button on the back cover.
- When using the megaphone, place your lips as close as possible to the megaphone when speaking. Adjust the **'Volume Control'** to the desired level without causing any howling or feedback.
- Press the **'Music'** button to activate soft music. Or press the **'Siren'** button to activate emergency siren/alarm. To switch off the alarm, press the same button again, or press the **'ON/OFF'** button.



PRECAUTIONS

Ensure correct polarity of cells used. Insert the batteries in the correct direction by aligning the (-) marks on the batteries with the spring in the back cover. Use new batteries/cells whenever possible. When the megaphone is not in use for a long period of time, remove the dry cells and replace. Drained cells or rechargeable battery will not give sufficient sound volume.

Features:

- Compact Megaphone Speaker
- (2) Audio Projection Modes: Voice Talking & Siren Alert
- Voice Mode: Amplifies Your Voice as Spoken into the Microphone
- Siren Alert Mode: Amplifies an Emergency Tone Through the Megaphone Speaker
- Battery Operated, Requires (4) x 'C' Batteries, Not Included
- Ergonomic Pistol Grip and Light-Weight Chassis
- Quick Folding Handle for Portability
- Adjustable Volume Control
- Power Saving OFF Switch
- For Indoor/Outdoor Use

Technical Specs:

- Power Output: 30 Watt MAX
- Audio Projection Range: Up to 800+ Yards
- Battery Operated:
Requires (4) x 'D' Batteries, Not Included
- Dimensions (D x H): 6.25" x 10.0"-inches
- Weight: 1.06 lbs



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?

PyleUSA.com/ContactUs

PYLE