

OUTDOOR BUG ZAPPER USER MANUAL





INSTALLATION INSTRUCTIONS

- Remove the equipment from the box.
- Fix the capture container on the equipment bottom.
- Check that the lamps are secured on the special housings (hands protected with gloves or insulating paper or cloth).
- Fix the equipment on the special stand.
- Connect the power supply cable to the equipment.
- Check that the cable is stretched to prevent people from stumbling or to prevent other inconveniences.
- Insert the cable plug into the power socket (protected by a circuit-breaker).
- Check that all electric controls operate perfectly.
- Verify that the capture exit prevention device is open,
- Activate the fan control.
- Activate the light control.

Keep in mind that capture heights may vary from 50 to 170 cm (in such case the equipment may be hung by using the special ring).

USE WARNINGS

- If the equipment is placed outside, it must be covered and protected from bad weather.
- Do not position the equipment near heat, gas or flammable product sources.
When the equipment is not used, disconnect the plug from the power socket (power off the transformer and equipment power cable).
- Position the equipment so it is not within easy reach of children and pets.
- Before cleaning and/or servicing the equipment, turn off the lamps, turn off the fan, close the capture exit prevention device and disconnect the power cable plug from the power socket.
- Check that the power socket for the power cable is protected by a circuit-breaker.
- Ensure that the equipment positioning site is away from condensation points and water splashes.

- Do not start the equipment if the power cable or the power socket is damaged.
- Do not force the protections while the equipment is operating.
- In case of use of a power cable extension, ensure that the junction point is protected against all possible negative effects (water, tears, shocks, short-circuits, etc.).

MAINTENANCE

COLLECTION COMPARTMENT EMPTYING

1. Switch the trap off.
2. Disconnect the adapter with cable from the power socket.
3. Disconnect the cable from the trap.
4. Wait for 2 to 3 minutes.
5. Remove the capture collection tray.
6. Remove the bait if inserted,
7. Empty the collection compartment and clean it by means of a semi-rigid bristle brush (also by means of special non-corrosive cleaners if necessary). Keep in mind that dehydrated captured insects not subjected to chemical or biological agents may be left outside for feeding birds and insects.
8. When finished cleaning, reassemble the components, in reverse order, by taking great care and paying maximum attention while operating,

LAMP REPLACEMENT

1. Switch the trap off.
2. Disconnect the adapter from the power socket
3. With well dry or protected hands, rotate the lamp by 90° and remove it from the seat.
4. Insert the new lamp (use the recommended model) and rotate it by 90° in the reverse direction compared to that of the removal