

PYLE
PyleUSA.com



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

PYLE

Questions? Issues?
We are here to help!
Phone: (1) 718-535-1800
Email: support@pyleusa.com

PYLE
PyleUSA.com



PPHP152BMU
Portable Wireless BT PA Loudspeaker System
Built-in Rechargeable Battery, MP3/USB/SD Readers,
FM Radio, 15" Subwoofer, 1000 Watt

User Manual

We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the Portable PA Speaker and Microphone System. We also recommend that you keep this manual in a safe and handy place for future reference.

CAUTION

WARNING! DON'T OPEN THE MACHINE TO AVOID ELECTRIC SHOCK, PLEASE ASK HELP FROM PROFESSIONAL TECHNICIANS.




SAFETY INSTRUCTION

1. Read this manual carefully before using. Retain for future reference.
2. All warnings on the speaker and in the operating instructions should be adhered to.
3. Do not use this apparatus near water.
4. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not install the speaker in an airtight location.
5. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
6. Switch OFF and unplug then use a soft cloth to clean the exterior of the unit if it becomes dirty. If necessary, use a damp cloth that has been wrung out well to wipe it.
7. Unplug this apparatus during lightning storms or when unused for long periods of time.
8. Keep foreign objects and liquid from entering the unit to avoid a short circuit, fire and electrical accidents.
9. Place the speaker in a dry location.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Control & Layout

Front Panel & System

1. SD Card Input
2. Screen
3. EQ Selectors
4. Remote Control
5. Input Selectors
6. Repeat Control
7. EQ Switch
8. Line-in (AUX) Input
9. Audio Output Jack
10. DC Input Jack
11. FM Antenna
12. Voltage Selector Switch
13. Power Switch
14. USB Input
15. Play/Pause Control
16. Next Song/Volume Up
17. Previous Song/Volume Down
18. Full Voltage Indicator
19. Volume Control
20. Charge Indicator
21. Mic Input Jack
22. Mic Priority Switch
23. Mic Volume Control
24. Echo Control
25. Guitar Volume Control
26. Guitar Input Jack
27. AC Input Jack



FM Radio

1. Turn **ON** the unit.
2. Press Mode selector, set to Radio mode;
3. You can use FM selector choose for FM;
4. When you use the radio for the first time, press Scan once, unit will auto search and store radio stations, then you can use **PRE/NEXT** to select the stored radio stations.
5. You can also use the **PRE/NEXT** buttons to manual search for radio stations.
6. You can use the six numbers located on top panel to store your favorite radio stations.

NOTES:

FM reception maybe different in locations, for better reception quality, please use the Antenna and keep unit far from any electrical distortions.

USB/SD Card Playback

You can play music from USB stick or SD Card using the USB/SD slot on the PA speaker.

1. Turn **ON** the unit.
2. Insert your USB or SD card into the slot.
3. Once inserted the USB or SD card unit will automatically play.
4. You can use the **PRE/NEXT/PLAY/PAUSE** to control and play music.

NOTES:

The speaker system can play the following audio file formats: MP3, MP4, WMA.

The USB/SD Card max size is 32GB. Operation may be slower when searching large memory files. It will need several seconds to respond when your USB/SD Card full of contents.

Wireless BT Playback

You can connect your Wireless BT phone or other device to the PA speaker.

1. Turn **ON** the unit.
2. Press the **INPUT** button which is located on top control panel.
3. The BT is **ON** when you hear two tone indicator sound.
4. Use your Wireless BT phone or other device to search for the Wireless BT name "PYLE SPEAKER".
5. Select the "PYLE SPEAKER" Wireless BT name and wait for the device to pair automatically.
6. You do not need password and get connected with unit.
7. You can use the **VOLUME/BASS/TREBLE** to adjust the sound level for Wireless BT, also you can adjust the Wireless BT music sound through your own phone or other device.

NOTES:

Check the volume controller both on the unit and on your phone or other device if there is no sound through the PA speaker during Wireless BT.

Use of External Power

To use the PA speaker longer than the Internal battery life, you can connect the PA speaker to a external 12V Battery Source.

1. Find the INPUT DC 12V on the top control panel.
2. Use the correct cable to connect the INPUT DC 12V.

NOTES:

The PA speaker will consume the internal battery first, when it is low, the LOW BATTERY indicator light located on the control panel will turn on, you can use the external 12V battery to power on the unit. The external 12V battery will also charge the internal battery while in use.

System Features:

- Portable PA Loudspeaker
- Built-in BT for Wireless Music Streaming
- Sound System: 15" Subwoofer and 5" Tweeter
- USB Flash and SD Memory Card Readers
- 5 Band Music Channel EQ with Blue LEDs
- Touch Button Audio Controls
- Digital Display Screen with FM Radio
- Displays Song Number and Play Time
- Auto Scan and Store for Radio Stations
- Built-in Rechargeable Battery
- Battery Life up to 3 Hours, Non-Stop Play
- 1/4" Microphone and Guitar Input Connector Jacks
- RCA (L/R) Input and Output Connector Jacks
- Master, Mic, Echo, Guitar Volume Controls
- Retractable Handles and Caster Wheels for Easy Transport
- Heavy Duty Handles for Portability
- Rugged, Durable and Reliable Housing

What's in the Box:

- PA Speaker System
- Handheld Microphone
- Remote Control
- Audio Connection Cables
- Power Cable

Wireless BT Connectivity:

- Built-in Wireless BT Music Streaming
- Works with All of Your Favorite Devices
(iPhone, Android, Smartphone, iPad, Tablet, Computer, etc.)
- Wireless BT Network Name: Pyle Speaker
- Wireless BT Range: Over 65'+ ft.

Technical Specs:

- Maximum Power Output: 1000 Watts
- RMS Power Output: 500 Watt @ 4 Ohm
- Battery: 7.5 Amp
- Average Charge Time: 8 Hours
- Max. USB/SD Card Size: 32GB
- MP3 File Compatibility
- Molded Speaker Cabinet Material: Engineered ABS
- DC 12V Input
- Power: 110/220 Voltage Selector
- Magnet: 40 Oz.
- Tweeter Type: Piezo
- Impedance: 4 Ohm
- Sensitivity: 90 dB
- T.H.D.: 10%
- Frequency Response: 20-20kHz
- Crossover Frequency: 3.5kHz