

**PYLE**  
PyleUSA.com



**VISIT US ONLINE:**  
Have a question?  
Need service or repair?  
Want to leave a comment?  
[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

**PYLE**

**Questions? Issues?**  
We are here to help!  
Phone: (1) 718-535-1800  
Email: [support@pyleusa.com](mailto:support@pyleusa.com)

**PYLE**  
PyleUSA.com



**PPHP122SM**  
12" Subwoofer, 800 Watt MAX



**PPHP152SM**  
15" Subwoofer, 1200 Watt MAX

**PPHP122SM - PPHP152SM**  
**Wireless BT Streaming PA Speaker**  
**and Microphone System**

Portable Karaoke Speaker with Wired Mic,  
Built-in LED Party Lights, FM Radio,  
MP3/USB/Micro SD Readers, Speaker Stand

**User Manual**

## WARNING



1. **DO NOT** place objects on top of the device, as objects may scratch the device.



2. **DO NOT** expose the device to dirty or dusty environments.



3. **DO NOT** insert any foreign objects into the device.



4. **DO NOT** expose the device to strong magnetic or electrical field.



5. **DO NOT** use the device in the rain



6. Please check with your Local Authority or retailer for proper disposal of electronic products.



7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.




8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

**Illegal operation may cause personal injury, which could be fatal and may cause damage to property.**


## CONTROL BOARD FUNCTIONS

1. USB Control board
2. USB and MICRO SD Memory Card input jack
3. Master volume control knob
4. 3.5MM AUX input jack
5. Power switch for LED light
6. Power ON/OFF switch
7. Echo volume control knob
8. Microphone volume control knob
9. Charge LED indicator, red color for charging mode and blue color for fully charged.
10. DC 9V input jack
11. 6.5MM microphone input jack



## REMOTE CONTROL FUNCTIONS

1. Standby button
2. Choose input AUX/FM/BT/USB signal
3. Mute button
4. Play/Stop button on MP3 mode, scan function on FM mode.
5. Next song on USB/Micro SD card, next channel on FM mode.
6. Previous song on USB/Micro SD card, last channel on FM mode
7. EQ effect on MP3 mode
8. Increase speaker volume
9. Choose song number directly on MP3 mode
10. Stop button
11. Decrease music volume
12. Repeat song on USB/Micro SD memory card



## TROUBLESHOOTING

Fault	Possible Cause	Solution
No sound	1. No input sound source. 2. Volume is too low.	1. Use a better music signal. 2. Adjust volume.
Distortion of sound	1. Volume too high. 2. Speaker may be damaged	1. Turn down the volume. 2. If speaker is damaged, repair or replace it.
Karaoke does not work	1. Microphone plug is not fully inserted. 2. Microphone switch is not on. 3. Microphone volume knob is at the lowest position.	1. Plug microphone properly into the socket. 2. Turn on microphone switch. 3. Adjust microphone volume properly.
MP3 does not play	1. The audio format in the U disc is incorrect. 2. Improper operation has caused a process disorder. 3. USB disc is disconnected.	1. Convert audio format into Mp3 format. 2. Reboot the machine. 3. Insert USB disc properly.

## PPHP122SM - PPHP152SM

**Wireless BT Streaming PA Speaker and Microphone System**  
 Portable Karaoke Speaker with Wired Mic, Built-in LED Party Lights,  
 FM Radio, MP3/USB/Micro SD Readers, Speaker Stand

MODEL	PPHP122SM	PPHP152SM
Power Output	800 Watt MAX	1200 Watt MAX
Speaker Stand Height	3.2' ft.	3.7' ft.
Sound System	12" Subwoofer, 1" Tweeter	15" Subwoofer, 1" Tweeter
Total Speaker Size (L x W x H)	13.5" x 11.6" x 21.3" -inches	16.9" x 14.2" x 26.3" -inches

## Features:

- Portable PA Speaker System
- High-Powered Loudspeaker Design
- Wired Microphone for Home Karaoke Style Fun
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- FM Radio with Digital LCD Display
- Built-in Rechargeable Battery
- Ported Enclosure for Extended Bass
- Full Range Stereo Sound Reproduction
- Sleek & Stylish Speaker Cabinet Housing
- Connect & Stream Audio from External Devices
- MP3 Audio File Playback
- USB Flash Memory Reader
- Micro SD Memory Card Reader

- Aux (3.5mm) Input Jack
- 1/4" (6.5mm) Microphone Input
- Low Battery Level LED Indicator Light
- Rugged & Durable Molded Cabinet Design
- Convenient Rolling Wheels & Extending Carry Handle
- Used for Public Gatherings, Crowd Control, Karaoke Vocals, Stage Performances
- For Indoor/Outdoor Use

### Wireless BT Streaming:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 5.0
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32' ft.

### What's in the Box:

- PA Speaker System
- Speaker Stand
- Wired Microphone
- Remote Control
- Power Adapter

### Technical Specs:

- Wired Mic Cable Length: 9.8' ft.
- Speaker Stand Height: 3.2' ft.
- Impedance: 4 Ohm
- Frequency Response: 55-20kHz
- S/N Ratio: 60dB +/-3dB
- SPL: 94dB (1W/M)
- T.H.D.: <1%
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Mic Nominal Current Drain: < 100mAh
- Construction Material: Polypropylene (PP)
- Battery Life: Up to 2+ Hours
- Battery Operated Remote: (1) x CR-2025 Button Cell, Included
- PA Speaker Battery Type: 7.4V Li-ion - 1800mAh
- Speaker Power Supply: 120/240V, Adapter (9V)



This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.