

**PYLE**  
PyleUSA.com

**PYLE**  
PyleUSA.com



**VISIT US ONLINE:**  
*Have a question?*  
*Need service or repair?*  
*Want to leave a comment?*  
[PyleUSA.com/ContactUs](http://PyleUSA.com/ContactUs)

**PYLE**

***Questions? Issues?***

We are here to help!

Phone: (1) 718-535-1800

Email: [support@pyleusa.com](mailto:support@pyleusa.com)



***PPHP42B***

Wireless BT BoomBox Stereo Speaker System  
Built-in Full Panel LED Lights, FM Radio/Aux/MP3/  
USB Flash Drive Memory Reader/Micro SD  
and 1/4 Input Jack for Microphone

***User Manual***

## WARNING



1. **DO NOT** place objects on top of the device, as objects may scratch the device.



2. **DO NOT** expose the device to dirty or dusty environments.



3. **DO NOT** insert any foreign objects into the device.



4. **DO NOT** expose the device to strong magnetic or electrical field.



5. **DO NOT** use the device in the rain



6. Please check with your Local Authority or retailer for proper disposal of electronic products.




7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.



8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

**Illegal operation may cause personal injury, which could be fatal and may cause damage to property. For safety, we do not suggest to charge unit and use microphone together.**

## CONTROL BOARD FUNCTIONS



1. Short press to choose input signal, press and hold to turn off front light
2. Short press to choose next channel, press and hold to increase sound volume
3. Short press to Play/stop on USB/Micro SD mode, press and hold to start TWS function.
4. Short press to choose last channel, press and hold to decrease song volume
5. Turn ON/OFF unit
6. 6.5MM microphone input jack
7. 3.5MM AUX input jack
8. Charge LED indicator
9. USB/Micro SD slot
10. DC 5V input

### TWS - True Wireless Setup


1. Turn on two same PA speakers that you're attempting to pair together and switch both units to Wireless BT mode.
2. Choose one of the unit to begin pairing process.
3. Press down on the PLAY ►|| button for 3 seconds until you hear a chiming sound; This means the unit is already paired with another unit.
4. Now begin playing your music through Wireless BT enabled mobile device. The speakers will begin to play your music simultaneously.

### NOTE:

**TWS function is for two speakers at a time only. It can not support more than two speakers at the same time.**

## REMOTE CONTROL FUNCTIONS

1. Standby button
2. Choose input AUX/FM/BT/USB signal
3. Mute button
4. Play/Stop button on Mp3 mode, scan function on FM mode
5. Next song on USB/Micro SD Card, next channel on FM mode
6. Previous song of USB/Micro SD Card, last channel on FM mode
7. EQ effect on Mp3 mode
8. Increase speaker volume
9. Choose song number directly on Mp3 mode
10. Stop button
11. Decrease music volume
12. Repeat song on USB/Micro SD Card



## TROUBLESHOOTING

Fault	Possible Cause	Solution
No sound	1. No input sound source. 2. Volume is too low.	1. Use a better music signal. 2. Adjust volume.
Distortion of sound	1. Volume too high. 2. Speaker may be damaged	1. Turn down the volume. 2. If speaker is damaged, repair or replace it.
Karaoke does not work	1. Microphone plug is not fully inserted. 2. Microphone switch is not on. 3. Microphone volume knob is at the lowest position.	1. Plug microphone properly into the socket. 2. Turn on microphone switch. 3. Adjust microphone volume properly.
MP3 does not play	1. The audio format in the USB is incorrect. 2. Improper operation has caused a process disorder. 3. USB disc is disconnected.	1. Convert audio format into Mp3 format. 2. Reboot the machine. 3. Insert USB disc properly.

### Wireless BT Connectivity:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 5.0
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32' ft.



WARNING:

This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.

### Features:

- True Wireless Stereo System
- High-Powered Speaker System
- Wireless & Portable BoomBox Stereo
- Bluetooth Wireless Music Streaming Ability
- Multi-Color Flashing full panel LED Lights
- Built-in LED Lights for Stunning Visuals
- FM Radio with Digital LED Display
- Built-in Rechargeable Battery
- Aux (3.5mm) Input
- MP3 Digital Audio File Support
- Connect & Stream Audio from External Devices
- USB Flash Drive Memory Reader
- Micro SD card reader
- 1/4" Input Jacks for Microphone
- Ported Enclosure for Extended Bass Response
- Integrated Extending Carry Handle
- Convenient Carrying Strap



### What's in the Box:

- Speaker System
- Remote Control
- USB charging cable
- Carrying Strap

### Note:

*You can use USB cable to connect 5V adapter (not included) to charge the unit.*

### Technical Specs:

- Max Power Output: 120 Watts MAX
- Sound System: 4" speaker x 2
- Digital Media File Compatibility: MP3, WMA (USB 2.0)
- Maximum USB Flash Drive Support: Up to 32GB
- Housing Construction Material: Engineered PP + Iron Net
- Built-in Rechargeable Battery: Li-ion 1800mAh, 3.7V
- Battery Operated Remote Control:
  - 1 Piece Button Cell Battery CR-2025 (Included)
- Power Supply: 110/240V (5V Power Adapter, not included),  
USB Cable included
- Dimensions (L x W x H): 12.1" x 6.1" x 5.6" -inches

