



# **Questions? Issues?**

We are here to help!
Phone: (1) 718-535-1800
Email: support@pyleusa.com





# PPHP854B

# 8" Wireless BT Portable PA Speaker

Portable PA & Karaoke Party Audio Speaker with Built-in Rechargeable Battery, Flashing Party Lights, MP3/USB/ /FM Radio (300 Watt MAX)



#### WARNING



1. **DO NOT** place objects on top of the device, as objects may scratch the device.



2. **DO NOT** expose the device to dirty or dusty environments.



3. **DO NOT** insert any foreign objects into the device.



4. **DO NOT** expose the device to strong magnetic or electrical field.



5. **DO NOT** use the device in the rain



6. Please check with your Local Authority or retailer for proper disposal of electronic products.




7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.



8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

Illegal operation may cause personal injury, which could be fatal and may cause damage to property.

#### **FRONT PANEL FUNCTIONS**




- 1. Master volume control
- 2. Charge LED indicator
- 3. DC 5V input jack
- 4. Short press to choose input signal, press and hold to turn ON/OFF light
- 5. Next/select saved radio station.
- 6. Play/Pause/TWS function/In FM mode, press and hold to search radio station automatically and save.
- 7. Previous/select saved radio station
- 8. AUX input jack
- 9. USB input jack
- 10. Microphone input jack
- 11. Display screen

2 www.PyleUSA.com www.PyleUSA.com 3

### **REMOTE CONTROL FUNCTIONS**

- Power: Used to turn on and off the MP3 player power
- 2. **MODE:** Used to switch the AUX/ USB/Wireless BT/Radio
- 3. Mute button
- 4. Play/Pause/Press and hold for TWS/ In FM mode, press and hold to search radio station automatically and save
- 5. Next song/In FM mode, short press to select saved radio station
- 6. Previous song /In FM mode, short press to select saved radio station

- 7. EQ solution
- 8. Increase volume
- Choose song number directly/In FM mode, choose FM Frequency directly
- 10. Choose USB or SD signal directly(Only suitable for models with USB & SD both)
- 11. Decrease volume
- 12. Repeat song



#### **TWS FUNCTION**

For increase sound effect, our unit provides TWS function as follows:

- **Step-1:** Turn ON BT mode on your device and connect the machine.
- **Step-2:** Press and hold each control board "**TWS**" button more than 3's, and you will see "**ON**" on display, unit will start to connect the other unit automatically, now you can enjoy stereo sound, and adjusting one unit volume will affect the other unit.

#### **Remark:**

1. After connection, press and hold again one of control board "**TWS**" button more than 3's, you will see "**OFF**" on display, unit's TWS disconnection.

### **TROUBLESHOOTING**

Fault	Possible Cause	Solution
No sound	<ol> <li>No input sound source.</li> <li>Volume is too low.</li> </ol>	Use a better music signal.     Adjust volume.
Distortion of sound	<ol> <li>Volume too high.</li> <li>Speaker may be damaged</li> </ol>	Turn down the volume.     If speaker is damaged, repair or replace it.
Karaoke does not work	<ol> <li>Microphone plug is not fully inserted.</li> <li>Microphone switch is not on.</li> <li>Microphone volume knob is at the lowest position.</li> </ol>	<ol> <li>Plug microphone properly into the socket.</li> <li>Turn on microphone switch.</li> <li>Adjust microphone volume properly.</li> </ol>
MP3 does not play	<ol> <li>The audio format in the U disc is incorrect.</li> <li>Improper operation has caused a process disorder.</li> <li>USB disc is disconnected.</li> </ol>	<ol> <li>Convert audio format into Mp3 format.</li> <li>Reboot the machine.</li> <li>Insert USB disc properly.</li> </ol>

#### Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Rugged & Durable Molded Cabinet Design
- Convenient Extendable Carry Handle
- For Indoor / Outdoor Use

## Wireless BT Streaming:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 4.2
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32'ft.

## What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Straps

## **Technical Specs:**

- Material: Polypropylene (PP)
- Max Power Output: 300 Watt Max
- Sound System: 8" -inch Subwoofer
- Impedance: 3.0 Ohm
- Frequency Response: 50Hz-12KHz
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 2 Hours (Charge Time: Approx. 4 Hours)
- Rechargeable Battery: 3.7V, 1800mAh 6.66 Wh
- Power Supply: 120/240V, Switchable (5V/2A Power Adapter)
- Dimensions (L x W x H): 9.9" x 6.5" x 11.8" -inches



This product can expose you to a chemical or group of checmicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth warning: defects, or other reproductive harm. For more info, go to https://www.p65warnings.ca.gov/.