

USER MANUAL



PPHP8MBA

Wireless BT Streaming Portable PA Speaker System

Compact Loudspeaker with Built-in Rechargeable Battery, MP3/USB/SD/FM Radio In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.









Caution: To reduce the risk of electric shock do not open this device, there are no serviceable parts for customers. Please refer any maintenance or repair to qualified personnel.



This sign means the existence of dangerous voltage at the inside of the unit, which states a risk of electric shock.



This sign means that there are important instructions of operation and handling in the manual that comes with this device.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

WARNING:

When using electric products, basic precautions should always be followed, including the following:

- Read all instructions before using the product.
- Do not use this product near water, i.e. a bathtub, sink, web basement, or swimming pool.
- This product, in combination with other headphones and speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for long periods of time at a high-volume level or any level that is uncomfortable. If you experience any hearing loss or ringing in the ears, consult a doctor.

- The product should be located away from heat sources such as radiators, heat resistors, or any other product that produces heat.
- The product should be connected to a designated power supply described in these instructions.
- The power supply cord should be unplugged when left unused for a long period of time.
- Care should be taken so that objects do not fall or liquids are not spilled into the enclosure through its openings.
- The product should be serviced by quality personnel when:
 - 1. The power supply cord or plug has been damaged
 - 2. Objects have fallen, or liquid has been spilled in the product
 - 3. The product has been exposed to rain
 - 4. The product does not appear to operate normally or exhibits a marked change in performace
 - 5. The product has been dropped, or the enclosure damaged
- Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be performed by quality service personnel.

INSTRUCTION

Before connecting the speaker, make sure the system is off and the controls on the minimum level. On the contrary the system could damage:

- 1. Plug the **AC** plug to electric power and to the speaker.
- 2. Plug the microphone on the "MIC" input with a 6.3 connector or Canon.
- 3. Plug an auxiliary system (**CD,DECK,MP3,DVD.etc**) on "**LINE IN**" input
- 4. Turn on the systems. A green **LED** light up on the speaker to indicate it is on.
- 5. Set the volume on the middle level on the **MIC** and **LINE IN** input.
- 6. Increase little by little the master volume
- 7. Set TREBLE/BASS controls to equalize the sound.

CAUTION

- Instructions are intended to alert the user to the risk of injury or material damage, should the unit be used improperly.
- Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well as to domestic animals or pets.

BLUETOOTH OPERATING PROCEDURES

Step 1:

Push the bottom "MODE", until to find " BLUE " on the display

Step 2:

Turn on smart phone bluetooth function, search for speaker box Blue connect --- "Bluetooth", no password to finalize the connection of Bluetooth between smart phone and speaker box.

Step 3:

Once the Bluetooth is connected between smart phone and speaker box, play the music on the smart phone, then please enjoy the big power sound from speaker box!

CHARGING OPERATING PROCEDURES

Step 1:

Please refer to point 7. Power indicator (Amplifier control), when the red LED flashes, the battery power is low, please stop playing music and press switch to OFF mode.

Step 2:

Put the AC adaptor to DC IN 15V for charging, the red LED will be ON

Step 3:

When the battery is fully charged, the blue LED will be ON, please unplug the AC adaptor .

CONTROLS

1. USB Display

- 2. USB and SD socket
- 3. Previous song/channel, long press this button to reduce the volume

4. Play/Pause

- 5. Next song/channel, long press this button to increase the volume
- 6. MODE: USB/SD/FM/BLUETOOTH/AUX function of conversion

7. Power Indicator

GREEN LED: ON

CHARGING: Red LED light on (Low battery, red LED will flash) **FULL:** Blue LED light on

8. MICROPHONE INPUT 1:

Balanced microphone Connector

9. MICROPHONE INPUT 2:

Balanced microphone connector

10. AUX INPUT

Allows cassette recorder or CD player to the Main output.

11. DC IN 15V

12. MICROPHONE VOLUME LEVEL

Allows you to increase or decrease the volume level.

13. ECHO

Allows you to increase or decrese the ECHO level

14. TREBLE


15. BASS

16. VOLUME

Allows you to increase or decrease the volume level.


17. ON/OFF SWITCH

Powers the device ON/OFF.



REMOTE CONTROL

- 1. MP3 ON/OFF
- 2. MODE: USB / Bluetooth function of Conversion
- 3. Loudspeaker mute
- 4. Play/Pause
- 5. EQ
- 6. KEY number for selecting the music
- 7. Last song
- 8. Next song
- 9 & 10. Reduce/increase the volume
- 11. REPEAT ONE/ALL.
- 12. USB Connect function of Conversion



PPHP8MBA

Wireless BT Streaming Portable PA Speaker System

Compact Loudspeaker with Built-in Rechargeable Battery, MP3/USB/SD/FM Radio

System Features:

- Versatile High-Powered Mobile Cabinet Speaker System
- Rugged, Durable & Reliable Sound
- Bluetooth Wireless Music Streaming Ability
- Built-in Rechargeable Battery
- Includes Wired Handheld Microphone
- Speaker System: 8" Subwoofer
- 2-Way Full Range Audio Projection
- Built-in Digital Audio Amplifier
- USB Flash Drive & SD Memory Card Readers
- FM Radio with Digital LCD Display
- Connect & Stream Audio from External Devices
- (2) 1/4" Microphone Inputs
- RCA (L/R) Stereo Line Input Jacks
- Charging LED Indicator Lights
- Rear Panel Button Control Center
- Heavy Duty Engineered ABS Housing
- Convenient Extendable Carry Handles & Rolling Wheels
- Master Volume, Mic Volume, Treble, Bass Setting
- Perfect for Karaoke, Crowd Control, Public Gathering Events

Bluetooth Wireless Streaming:

- Instantly Stream Music from Your Bluetooth Devices
- Works with All Your Favorite Bluetooth Devices (iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)
- Bluetooth Version: 2.1
- Bluetooth Network Name: 'BLUE'
- Wireless Range: Up to 100' ft.

What's in the Box:

- Portable PA Speaker
- Wired Handheld Microphone
- Remote Control
- Power Adapter

Technical Specs:

- Power Output: 360 Watt MAX
- Speaker Style: Molded Cabinet
- Magnet: 12 Oz
- Voice Coil: 0.75" -inch
- Amplifier Class: D
- Impedance: 4 Ohm
- T.H.D.: <1%
- Sensitivity: 92dB (+/-2dB)
- Mic Input Level: <15mV
- Line Input/Output Level: >250mV
- Frequency Response: 70-20kHz
- Digital Audio File Compatibility: MP3, WMA
- Maximum SD/USB Flash Memory Support: 32GB
- Remote Battery: Requires (1) x 'CR20-25' Button Cell, Included
- PA Speaker Rechargeable Battery: 12.1V Lead Acid, 3000mAh
- Power: DC 15V
- Dimensions (L x W x H): 13.4" x 10.4" x 18.9" -inches
- Sold as: 1

www.PyleUSA.com





VISIT US ONLINE: Have a question? Need service or repair? Want to leave a comment? PyleUSA.com/ContactUs

