



Pay attention:

1. Make the bottom triangle firstly, then add three uprights, then make the top triangle. When you make the triangle, for the last side, it is a little bit difficult, but it is designed intentionally in order to make the angle to be tensioned and not get loose.
2. Please don't cut the zip tie as you may use in next time.
3. This zip tie can be released again just by pressing the switch.
4. When you fix all the zip ties, you can tighten the tie a little by a little to make the screen as flat as possible.
5. You can leave the clip on or remove the clip later, as the clip is a tool helping you to fix the screen in the beginning.
6. These two pairs of gloves so it is better to have two persons to assemble this screen.
7. Don't tighten the screen too much otherwise the screen will be torn.
8. If the screen is dirty, you can clean it with a white cloth, the screen is not suitable for machine wash.
9. The screen can be used in door or outer door but it is not waterproof. You can not display outside the whole year as the black edge around will be damaged in water.
10. Once you finish using this screen, store the screen in the same way when you take them out. About the stand, you can use the spring stop of the zip tie to wrap them.

