

PYLE
PyleUSA.com



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

PYLE

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com



PSBV200BT









Wireless BT Soundbar Speaker System

300 Watt with USB/SD/FM Radio
and Wireless Remote

User Manual

**PLEASE READ THE INSTRUCTION MANUAL CAREFULLY
AND KEEP IT FOR FUTURE REFERENCE**


WARNING

-  1. **DO NOT** place objects on top of the device, as objects may scratch the device.
-  2. **DO NOT** expose the device to dirty or dusty environments.
-  3. **DO NOT** insert any foreign objects into the device.
-  4. **DO NOT** expose the device to strong magnetic or electrical field.
-  5. **DO NOT** use the device in the rain
-  6. Please check with your Local Authority or retailer for proper disposal of electronic products.
-  7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.
-  8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.



Illegal operation may cause personal injury, which could be fatal and may cause damage to property.

REMOTE CONTROL Functions

- 1. UNIT STANDBY MODE
- 2. CHOOSE SIGNAL INPUT
- 3. INCREASE MUSIC VOLUME
- 4. NEXT SONG/CHANNEL
- 5. DECREASE MENU VOLUME
- 6. DECREASE MUSIC VOLUME
- 7. INCREASE MENU VOLUME
- 8. MUTE
- 9. REPEAT
- 10. PLAY/PAUSE KEY
- 11. PREVIOUS SONG/CHANNEL
- 12. MENU



Control Board Functions




- 1. Power switch
- 2. Menu
Press and hold this button for 3 seconds to reset all volume.
Short press for as followings function:
EQ 1 3 Kinds of EQ music effect choosing
t 00 t (-6---+6) Music "treble" volume adjustment
b 00 b (-6---+6) Music "bass" volume adjustment
S r 50 3D sound effect turn ON/OFF, 0 mean OFF, 1 mean ON
u 30 b (-0---+30) Music volume adjustment

- 3. Input
L IN 1 Match front panel number 7 3.5MM AUX
L IN 2 Match back panel number 14 3.5MM AUX
RUX 1 Match back panel number 15 RCA
RUX 2 Match back panel number 16 RCA

- If there's no voice after connecting aux cable, please check input match**
- 4. Pre/VOL-
- 5. LCD display
- 6. Power indicator
- 7. Remote sensor
- 8. PLAY/PAUSE
- 9. Next/VOL+
- 11. SD slot
- 12. 3.5MM AUX IN

Back Panel Functions



13. PC MP3 input jack 15. AUX 2 L+R input jacks
 14. AUX 1 L+R input jacks 16. DC: 18V/2A

Troubleshooting and Warning

| Fault | Possible Cause | Solution |
|-----------------------|---|---|
| No sound | 1. No input sound source 2. Volume is too low | 1. Use a better music signal 2. Adjust volume |
| Distortion of sound | 1. Volume too high 2. Speaker may be damaged | 1. Turn down the volume 2. If speaker is damaged, Repair or replace it |
| Karaoke does not work | 1. Microphone plug is not fully inserted. 2. Microphone switch is not on 3. Microphone volume knob is at the lowest position | 1. Plug microphone properly into the socket 2. Turn on microphone switch 3. Adjust microphone volume properly |
| MP3 does not play | 1. The song format in the U disc is incorrect 2. Improper operation has caused a process disorder 3. USB disc is disconnected | 1. Transform song format into Mp3 format 2. Reboot the machine 3. Insert USB disc properly |



WARNING:

This products can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.

Features:

- Wireless BT Streaming
- 3D Surround Sound System: Total Five Speakers
- USB Flash & SD Memory Card Readers
- MP3 Digital Audio File Compatibility
- Aux (3.5mm) Input Connector
- FM Radio
- Ability to Connect External Devices
- (2) Pair RCA (L/R) Audio Input Jacks
- Full Range Stereo Sound Reproduction
- Ported Enclosure for Impressive Bass Response
- Home Theater, TV, Speaker System Compatible
- Front Panel Control Center & LED Display
- Built-in Sound Amplifier
- EQ Audio Configuration
- Sleek Piano-Black Glossy Finish
- Mac & PC Compatible

Wireless BT Streaming Connectivity:

- Built-in BT for Wireless Music Streaming
- Works with All of Your Favorite Devices (iPhone, Android, Smartphone, iPad, Tablet, Computer, etc.)
- Wireless BT Version: 5.2 version
- Wireless BT Range: $\geq 10M$

What's in the Box:

- SoundBar Speaker
- Audio Connection Cable, 3.5mm
- Remote Control
- Adapter

Technical Specs:

- Power Output: 300 Watt MAX
- Sound: (1) 5.25" Mid-Woofer, (2) 3" Full Range, (2) 1" Tweeters
- Impedance: Speakers 6 Ohm, Woofer 6.8 Ohm
- Channel Separation Rate (1kHz): > 40dB
- Frequency Response: 20Hz-20KHz
- Input Sensitivity: 500mV
- S/N Ratio: >70dB
- USB Connector: Type 2.0
- Digital Audio File Compatibility: MP3, WMA,
- Remote Control Battery Operated, (2) x 'AAA', Not Included
- Power Supply: DC 18V/2A
- Product Dimensions (L x W x H) 23.8" x 10.2" x 4.9" -inches