

Animal REPELLER USER MANUAL



PSLBAR8

PYLE[®]
PyleAudio.com


Solar Powered Animal Repeller

Locating the repeller:

When installing your repeller, choose a location that needs protection and also receives good sunlight. For best results, the repeller should receive at least 8 hours of sunlight. This repeller is designed for long term use, allowing you to place it and leave it to repel pests. It is weather proof allowing it to work all year around. The repeller can be hung or inserted into the ground using the ground stake provided. To use the ground stake, simply insert the flat end into the bottom of the repeller. **WARNING: ALWAYS CHECK FOR UNDERGROUND UTILITIES, CABLES OR WIRES BEFORE DIGGING OR INSTALLING. FAILURE TO CHECK COULD RESULT IN PERSONAL INJURY, PROPERTY DAMAGE OR EVEN DEATH.** After checking for underground utilities, prepare the ground for the stake by digging or pile driving a hole suitable for the repeller. Do not hit or strike the repeller unit or stake to drive it into the ground – this will damage the unit and void any warranty. Make sure the ground stake is firmly in the ground and not loose.

Using the repeller:

To operate, open the back cover using a Phillips head screwdriver and refer to the diagram below. Remove the tab / plastic barrier from the rechargeable batteries to allow contact. Normally, the repeller will be in standby mode. Only when motion is detected (range of 30' and arc of 110 degrees) will the repeller activate. There are 3 operating models described below. Before first use, please allow two full days of sunlight to charge the batteries while the repeller is in the "OFF" position.



Mode 1 – Audible Repellant - uses a series of seven different recorded sounds (GUN SHOT / SIREN 1 / BOAR SQUEAL / SIREN 2 / BANGING SOUNDS / SIREN 3 / DOG BARKING). The repeller will cycle through these sounds, preventing animals from getting used to any one sound and increasing its effectiveness. Adjust the loudness as needed.

Mode 2 - ultrasonic/infrasonic sound waves – uses a selectable scale of ultrasonic and infrasonic waves ranging from 12Hz to 35KHz. Refer to the control panel marking and set the frequency for the desired pest.

Mode 3 - combines modes 1 and 2 and uses both the audible noises and the ultrasonic/infrasonic sound waves.

Night time operation in any mode: the repeller contains a light sensor that automatically switches the repelling to flashing LED lights ONLY. Regardless of which mode it is in, the repeller will operate silently at night using 320 lumen of flashing LED light to repel pests.

Specifications:

1. Power Supply: 4 @ "AA" Rechargeable NI-CD 800mAh, 1.2 Volts.
2. Power Consumption: 0.2mA (standby) 80mA (working).
3. Frequency Range: 12Hz – 35KHz
4. Coverage Area: 6-8 meters 110 degree

NOTE:

1. Allow the repeller to work continuously for best results.
2. If Pets are in the protected area, turn the repeller OFF. Not for use near pets such as hamsters, gerbils and ferrets.
3. Do not immerse repeller in water.

Do not cover or block the motion detector.

4. To clean the unit; use a soft, damp cloth with mild soap and water. Do not use harsh chemicals or abrasive cleaning agents as these could damage the repeller. Keep the solar panel clean.
5. If you are not using the unit for a long period of time, remove the batteries. Always recycle or dispose of used batteries according in compliance with local, State and Federal regulations.

WARNING: Disassembly of the electronic components within this unit may result in exposure to lead in the form of solder, which is known to the state of California to cause cancer, birth defects and other reproductive harm. No replaceable parts inside the unit.