

BLUETOOTH SPLASH-PROOF SPEAKER & RADIO USER MANUAL




PSR16BT

PYLE
PyleAudio.com

1

Radio Mode:



Select the AM/FM mode by switching the knob



Turn on the volume along clockwise. Do not turn the volume knob 360°.



Adjust the tuner to the ideal frequency, while frequency is shown on display.

5

Features:

- This Bluetooth speaker/radio is designed for people to listen to the radio and their favorite music anywhere in the bathroom, kitchen, swimming pool, or anywhere wet.
- International Protection rating of IP44 (Sand-proof and Splash-proof)
- AM/ FM digital out read out, frequency shown on display
- Alarm Clock
- Bluetooth wireless distance up to ~30 ft.
- Designed with hanger and stand

Specifications:

Bluetooth version	3.0
Operating range (maximum)	30' (The transmission distance changed depending on the environment where the product is used.)
Impedance:	4ohm
Power Output	3 Watts, 50mm dia.
Power supply	AAA x 2 pcs for alarm clock Built in battery for radio/ Bluetooth
Current consumption:	500 mA (Max)
Continuous standby time: #	8-9 Hours
Playing time	4.5-5 hours (at middle volume level)
<small>#The actual continuous standby/transmission times may become shorter than those in the specifications depending on the environment or conditions for keeping/using the unit, etc. #Batteries are consumables. The battery service time gradually decreases after the charging and discharging cycles, even if the batteries are used properly. #The battery performance deteriorates quickly if the unit is kept under high temperature conditions. Please keep the unit in a cool, well-ventilated location, away from direct sunlight.</small>	
Operating Temperature:	32°F~113°F
Operating humidity range:	20-80% (no condensation)
Product size:	5.0" x 5.5" x 2.7" -inches
Waterproof performance:	IP44
Number of devices that can be registered	4

2

Bluetooth Mode:

1. Turn the mode knob to BLUETOOTH
2. At the first time to pair, search the product model "AM/FM Bluetooth Clock" by your smartphone.
3. When your smartphone searches the product model, choose to connect, your device will show if it is successfully connected or not.
4. If it is successfully connected, you can play music through the product.

Note:

Terminate any connection between the product and any device before starting the pairing procedure.

The pairing procedure cannot be started while a Bluetooth connection is established between the product and a registered device. Terminate the connection and turn off the product.

Up to four Bluetooth device can be registered:


When 5 or more devices are registered, the previously registered devices will be deleted starting from the oldest, to register new ones. A device that is registered twice or more is identified as one device.

Using Aux Line in:

1. No matter on AM/ FM/ Bluetooth mode, once the line in cable is connected to the plug, the speaker sound source will be linked from line in.
2. When the unit is connected to an audio device via an audio cable, please do not use the unit in a wet or damp environment, because the watertight cap cannot be closed to ensure waterproof performance.

6

Splash-Proof Bluetooth Speaker/Radio



FRONT

1. Frequency Turning
2. AM/FM/Bluetooth mode switch
3. ON/OFF/Volume knob
4. Showerproof Speaker
5. Display
6. Play back from previous track
7. Play / Pause
8. Play next track

BACK

9. Time set
10. Alarm set
11. Hour
12. Minute
13. Alarm on/off
14. Stand/Handle
15. AUX line-in
16. Battery door lock

Functions and Parts

1. Frequency Turning
2. AM/FM/Bluetooth mode switch
3. ON/OFF/Volume knob
4. Showerproof Speaker
5. Display
6. Play back from previous track
7. Play / Pause
8. Play next track
9. Time set
10. Alarm set
11. Hour
12. Minute
13. Alarm on/off
14. Stand/Handle
15. AUX line-in
16. Battery door lock

3

Caution:

- **Please take full precautions when setting the ringtone volume.**
When this product is paired with a mobile phone, a loud beep may give you a shock, which in turn may result in an accident. Gradually increase the volume from the minimum to set it appropriately.
- **Do not damage cables that are connected to this product.**
Fire and disconnection will result.
- **Never leave this product in a car.**
Leaving this product in a hot car cabin for many hours will result in rupture of the built-in battery, sparking, and other troubles, posing significant danger.
- **Do not leave this product under high temperature conditions.**
Avoid using/ keeping this product in a location that is subject to high temperature, high humidity or direct sunlight for many hours. When subject to significant temperature changes in the environment, this product may malfunction due to condensation inside the product.
- **Do not touch the metal parts of this product such as the power supply connectors and the charging cable's connector terminals.**
Static electricity or fouling may cause a malfunction or electric shock.
- **Do not disassemble this product.**
Do not repair, modify or disassemble this product on your own, unless operational instructions to the contrary are given in this user's manual. Electric shock, fire, or burns may result.
- **Make sure to close the watertight cap when using this product in a wet or damp environment.**
- **Make sure to remove any dust, hair, etc., that is present between the watertight cap and the battery door.**
- **Follow the user's manual instructions of devices (ex. iPhones and mobile phones) to be connected to this product.**
This product can be wirelessly connected to iPhones, mobile phones, etc. The setting procedures and precautions are different depending on the devices to be connected to this product.
- **Do not use/keep this product in a wet or damp environment for a long time if you do not use it.**
Any liquid entering this product may result in troubles, fire, or electric shock.
- **Do not keep this product within reach of small children.**
Unexpected accidents (ex. accidental ingestion) may result.

7

Alarm Clock Mode:

1. Install 2 pieces of AAA battery for the clock display.
2. Please follow the polarity indicated inside of battery compartment.
3. Hold (Time set) simultaneously press (Hour) to adjust the hour.
4. Hold (Time set) simultaneously press (Minutes) to adjust the minute.
5. Hold (Alarm set) simultaneously press (Hour) to adjust the hour.
6. Hold (Alarm set) simultaneously press (Minutes) to adjust the minute.
7. Press (Alarm On/Off) to turn alarm on or off/stop
8. When alarm function is turned on, the "☀" icon will be displayed.

Charging the Built in Battery for Radio / Bluetooth:

- When the battery is in low consumption, a beeping alarm will sound, with the LED lamp blinking red. After a while, product will turn off
- Charging the battery by using the provided USB charging cable.
- The LED lamp is lit red while the battery is charged.
- The LED lamp is turned blue when the battery is fully charged.
- It takes around 1 hour to fully charge the battery

4

8