

PYLE
PyleUSA.com



PSUFM1280B

Portable PA Speaker System Bundle Kit

with Built-in LED Lights, Rechargeable Battery,
Bluetooth Wireless Streaming, Handheld Microphone,
MP3/USB/Micro SD/FM Radio (12" -inch, 700 Watt)

USER MANUAL

To be sure you take maximum advantage of all the speaker has to offer, read these instructions carefully and use the set properly. Be sure to keep this manual for future reference, should any questions or problems arise.


CAUTION:

No user serviceable parts inside. Please return to the agents or a similarly qualified service centre for repair.

SAFETY INSTRUCTION

1. Please read the user manual carefully before use.
Retain for future reference.
2. All warning on the appliance and in the user manual should be adhered to.
3. Do not use the appliance near water.
4. Ventilation-do not block any of the ventilation openings.
 - Do not install near any heat sources or fire.
 - Do not install in an airtight location.
5. Keep the cord and plugs in good order.
6. The unit may be wiped down with a damp cloth once the unit has been switched off and the plug removed.
7. Unplug the during lighting storms or when not in use for long periods of time.
8. Keep foreign objects and liquid from entering the unit to avoid short circuit, fire and electrical accident.
9. Keep the appliance in a dry location.
10. Refer all servicing to the agent or a similarly qualified service centre for repair.

Front Board Function




Front Board Function

1. USB/Micro SD/FM/BT/AUX selection
2. Working status display window
3. MP3 last song/FM last frequency/Vol-
4. MP3 pause or play/FM auto scan frequency
5. MP3 next song/FM next frequency/Vol+
6. Record & Play
7. Mic priority

NOTE:

- The USB/Micro SD Memory Card input is ONLY meant to connect to a USB/Micro SD Memory Card flash driver (thumb drive). Connecting a MP3 player or computer .directly to the USB/Micro SD Memory Card flash drive input will result in the unit failing to play the audio from those devices.
- When in BLUETOOTH mode, it will auto search and match the Bluetooth you are using. After matching the Bluetooth, "PyleUSA" will show on the display screen and from the Bluetooth devices, you can easily find out "PyleUSA" Bluetooth name.

BACK BOARD FUNCTION




1. Mic jack and Guitar jack
2. Indicator light for charging states (red color for charging, green color is full charged)
3. Light ON/OFF
4. 12V DC charge
5. Electricity supply AC 120V -240V, 50/60Hz
6. The music volume: Adjust the musical instrument
7. Treble adjustment
8. Bass adjustment
9. USB/Micro SD Memory Card connector
10. Audio input: Audio signal input can connect DVD/VCD/AUX etc.
11. Mic echo adjustment
12. Mic volume adjustment
13. Power ON/OFF

REMOTE CONTROL

Remote Control Function

1. Standby mode
2. 0~9 Song selection
3. EQ selection
4. Play repeat
5. MP3 last song/FM last frequency
6. Sound volume " - "of main channel
7. MP3 pause or Play/FM scan frequency
8. Sound volume " + "of main channel
9. MP3 next song/FM next frequency
10. Shift between USB and Micro SD Memory Card
11. Mute
12. MP3/FM/BT/Aux input selection



The power switch must turn to "**OFF**" after using the speaker. Otherwise, the host built- in will continue to discharge the battery, eventually leading to the battery damage. If you will not use this speaker for a long time, you still have to charge the unit to protect the battery, our suggestion is that the battery needs to be charge every month. Otherwise, the electricity will be consumed and the battery will not charge again and will cause the speaker not to work in DC.

1. When noise occurs during use, staccato, or distortion, please replace the battery.
2. After use, please turn off the power switch.
3. When not in use for a long time, please remove the batteries to avoid leakage of battery acid corrosion of internal parts.
4. When turn on the power switch, such as the power indicator does not light or too dark, check whether the battery polarity is placed correctly or not.



Simple Troubleshooting

Symptom	Possible Problem	Solution
No function light & no sound	1. Plug is not well connected	Insert the plug into electrical outlet
	2. Speaker power button is not turned ON	Turn ON the button
Function light ON but no sound	1. Cable misconnected	Turn off the power, check the input jack to ensure proper audio signal is connected to relevant input jack
	2. Speaker are not connected or misconnected	Power off, then check and confirm the cable connection again
	3. Audio signal is not transmitted to speaker	Check all the speaker if there is audio signal output
If the problem exists after checking related procedures above, please refer to the appointed service agent or professional technician to fix it. Do not attempt to open the cover, otherwise we assume no responsibility		

PSUFM1280B

Portable PA Speaker System Bundle Kit

with Built-in LED Lights, Rechargeable Battery, Bluetooth Wireless Streaming, Handheld Microphone, MP3/USB/Micro SD/FM Radio (12" -inch, 700 Watt)

System Features:

- PA Loudspeaker System
- High-Powered Active Speaker Tower
- Hassle-Free, Quick Setup Audio & Vocal Projection
- Multi-Colored LED Flashing DJ Party Lights
- Bluetooth Wireless Music Streaming
- Built-in Rechargeable Battery for Portability
- Includes Wireless Handheld Microphone
- Mic Priority Control: Automatic Vocal Talkover over Music
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- USB Flash & Micro SD Memory Card Readers
- 1/4" Microphone / Guitar Input
- Aux (3.5mm) Jack
- Treble Bass Echo Volume Controls
- Full Range Stereo Sound Reproduction
- Impressive Bass Response
- Convenient Carry Handle & Wheels
- External Battery/Power Supply Support: DC 12V
- Perfect for Karaoke, Crowd Control, Public Even Gatherings

Bluetooth Connectivity:

- Instant Wireless Music Streaming Ability
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Bluetooth Version: 2.1
- Bluetooth Network Name: 'PyleUSA'
- Wireless Range: Up to 30'+ ft.

Audio Recording Mode:

- It's Easy: One Button Record Activation
- Record Audio as Streamed through the Speaker System
- Ability to Record Vocals via Microphone
- Records to USB Flash & SD Memory Card
- Audio File Type Created: .MP3

What's in the Box:

- PA Speaker with LED Lights
- Wireless Handheld Microphone
- Speaker Stand, 1.7' ft.
- Remote Control
- Audio Connection Cable
- Wall Power Cable

Technical Specs:

- Power Output: 700 Watt MAX
- Sound System: 12" Woofer, Horn Treble
- Frequency Response: 120Hz-15KHz
- Sensitivity (1w/1m): 650mV
- Impedance: 4 Ohm
- Maximum SPL: 128dB
- Dispersion (@6dB): H90 V50
- Crossover: 3kH LF: 120Hz-4kHz, HF: 4KHz-15KHz
- LED Lights Power Switch: ON/OFF
- Maximum USB Flash / Micro SD Memory Card Support: 32GB
- Microphone Battery Operated: Requires (2) x 'AA' Batteries, Included
- Rechargeable Battery: 11.1V Li-ion Battery, 1800mAh - 19.98Wh
- Power Supply: 110/220V
- Unit Dimensions (L x W x H): 13.7" x 12.9" x 26.3" -inches

PYLE

PyleUSA.com



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE