



PVRC75


HD Video Capture Pro

User Manual

With this PVRC75 HD Video Capture Pro, you can capture up to 1080P video from HDMI ,Ypbpr (component) or composite port, such as blue ray, set-top-box, computer, game box, VHS, etc. And you can playback the record movie directly.

PVRC75 has record and playback (two function) in one device, use button "MODE" to switch, blue LED "REC" means in recording mode, green LED "PLAY" means in playback mode.

FEATURES/PORTS AND BUTTONS:



1. **HOST-** Connect USB flash or HDD for saving recoded video file or still image
2. **DC-** DC 5V power supply.
3. **HDMI IN-** HDMI input.

4. **AV INPUT-** Cable comes with the package; to connect composite and component input.
5. **MIC-** Microphone input.
6. **LINE-** Line out.
7. **HDMI OUTPUT-** input video source to monitor.
8. **REC BUTTON-** Press to record, press again to stop recording.
9. **LEDs**
 - REC-** Red dot will flash when recording.
 - IR-** IR receiver.
 - 720-** 720 LED is on means it is now recording 720P video. You can also use the remote controller.
 - 1080-** 1080 LED is on means it is now recording 1080P video, You can also use the remote controller.
 - REC-** Blue is on at recording mode, set by button "MODE" or remote controller.
 - PLAY-** Green is on at play back mode, set by button "MODE" or remote controller.
10. **MODE-** Set mode between Recording and Play back

REMOTE CONTROLLER:

MODE- Set mode between Recording and Play back

RECORD AREA- Effect when switch to Recording mode



Start and stop recording



Capture one still image with one press. (Won't work during recording.)



Change record quality to 720P, will only effect when input source is more than 720P



Change record quality to 1080P, will only effect when input source is 1080P

PLAYBACK AREA

Hot Key- During playback, press this key to pop up quick menu, such as repeat mode video setting

EXIT- Shot press to back up one page, Long press to go back to home page



▶|| Play and pause

■✖ Mute

◀▶▲▼ OK Navigation key

⏮ ⏭ Previous and Next



⏪ ⏩ Fast backward and Fast forward

+/- Volume up and down

CONNECTIONS:


PVRC75 3 input modes: HDMI, component, and composite. It will automatically recognize the input video source.

Connect with HDMI input source:




1. Connect power with DC adaptor
2. Plug USB disk.
3. Use HDMI cable connect HDMI video source, such as game player, set top box, etc.
4. With HDMI cable connect to monitor
5. "LINE OUT" to connect speaker or earphone, it's not necessary if you don't need, cause the HDMI output also with audio output.
6. You can connect your microphone to record your comment when playing game, it's not necessary if you do not need it.

**CONNECT WITH YPBPR COMPONENT VIDEO SOURCE
(SUCH AS DVD PLAYER, PS3. ETC):**




1. Use the adapter cable in the package to connect component (red, blue, green), just don't mixed the red with the audio cable (the audio cable red and white will be separated with component)
2. The other connection will total same as HDMI connection above.


Note: For PS3 connect, you also need to do following settings:
Go to the settings---Video output settings, choose "Component / D-Terminal":



At the resolutions setting, make sure the "1080P" option is NOT ticked, otherwise some game play (e.g. GT5) cannot be recorded:



Connect with composite video source (such as camera, VHS, V8, Hi8, Etc):



1. Connect the composite (yellow cable and red white audio cable) to your video source with the adapter cable come with the package.
2. The other connections are all same as HDMI input connections above.

RECORD:

When power on PVRC75, it will be at default mode—Recording mode, the blue REC LED will be on.

After connection is ready (no matter composite, component, or HDMI), you should see the pass through video on the screen.

The 720P/1080P quality LED will shows on 1080P default if the input source is 1080P, this means on 1080P file recording, you can press the "720 " button of remote controller to set it to 720P, then the 720P LED shows on, means the recorded file will be 720P.

If the input source is under 1080P, then the LED only shows on 720P, and the "720/1080" button will not take effect, means only record 720P or under 720P file (base on input quality).

To record video is very simple --- press the REC button (or remote controller), and then you will see the red REC indicator turns on, it means recording is in progress.

Use SNAPSHOT button of remote controller, you can get a still image by one press, but it is only work when NOT recording.

Recording comments during video recording: If you connect a Microphone to MIC port, you can record comments with video.

There are several reasons for no actions after you press record button, you may need check:

1. The input video source disconnected.
2. The USB flash is out of storage memory.
3. The format for USB flash is not suitable, e.g. exFAT. PVRC75 support FAT, FAT32, and NTFS.
4. The USB flash is not connected well.
- 5, The USB flash is not ready, normally, it will take 4~8 seconds after plug it on.

To stop recording, just press the button again, will see REC indicator flash few seconds then turns off, means the record is stop, now you can take off your USB flash.

Note: please do not take the memory off when the indicator is flashing. The recording will automatically stop if the USB flash and there is no more storage space.

After stop recording, connect the USB flash to computer will see the recorded files: for 1080P recording, file will be Encode_1080P_1, for 720 or 480p recording, file will be Encode_1.

Every record/stop operation will create a different recording file: Encode_1080P_1, Encode_1080P_2, Encode_1080P_3... and so on.

The max size per file will be around 1.95GB (around 15 minutes for 1080p video), when you record a video more than 1.95GB (15 minutes), PVRC75 will partition it in more than 1 file, for example: if you record a 45 minutes 1080p video by one click recording, you will see 3 files: Encode_1080P_1, Encode_1080P_1_1, Encode_1080P_1_2...and so on

Sometimes you may find that some recorded video with problems, like: skip. It may caused by you are using a USB flash on NTFS format, and you haven't click "safety remove" the device when disconnect from computer (especially for USB HDD, if not safety remove, may caused serious problem). You can try to format it to FAT32 if that problem keeps happening.

PLAYBACK:

After recording, you may want to playback the recorded file. Just press the "MODE" button, then you will see the green "PLAY" led goes on (the blue "REC" led be off), in few seconds, you will see the playback page on your screen:

Use remote control to choose movie, recorded video to playback, or photos if you want see the snapshot pictures. Choose "File Manager" can play both video and picture.



Choose "Setup" to set Language or other options:



FIRMWARE AND OTHERS:

1. Update firmware: you maybe need update firmware for this device for some reason. Copy the firmware file in to USB disk, power off the device (unplug power jack), plug USB disk to device, power on, the red REC indicator will flash 7~8 seconds, it means the update is finished.
2. After long time using, you will see the number of recording file become too big, for example Encode_1080P_234, but you want it be start from Encode_1080P_0, to do it you just keep press record button (do not connect USB storage) 4 seconds, when you see the red REC led flash, the file number will start from 0.
3. Change the date: you may find out that the date of the recorded file is not synchronous with your local time. To change the time of PVRC75, you need create a TXT file name "rtc_setup" (It should be in including software CD), type your local date and time with following format (for 2014 July 31 11:00:00):

/:2014
/:7
/:31
/:11
/:00
/:00
/:0

Should be exactly same format as it (first line be year, second line be month..etc, end with /:0 , each line with start "/:/" , and save it.
Then copy the rtc_setup file to USB flash, connect to PVRC75 then power on, then the time is set ready.

SPECIFICATIONS:

Connections

INTERFACE	USB 2.0 Host
VIDEO INPUT	Digital: HDMI
	Analog: Component Video, Composite Video
AUDIO INPUT	Digital: HDMI
	Analog: 3.5mm MicroPhone In.
	Note: Microphone without pass through fo HDMI input
VIDEO OUTPUT	Digital: HDMI (Pass-through from HDMI or Component or Composite Input)
AUDIO OUTPUT	Digital: HDMI (Pass-through from HDMI or RCA L/R Input)
	Analog: 3.5mm Stereo (Pass-through from HDMI or RCA L/R Input)

Applicable Connections with Game Consoles

HDMI	Industry HD camera, HD Medical endoscope, TV, gameplay, etc
COMPONENT	TV, gameplay, etc
COMPOSITE	Industry camera, Medical endoscope, TV, gameplay, etc

Hardware Extra

CODEC	Hardware H.264 encoder
USER INTERFACE	Record button, mode switch button.
	LED indicator for working status.
	infrared receiver
DIMENSIONS	164(L) × 98(W) × 28(H) mm
WEIGHT	451g

Package Contents

DEVICE	PVRC75 HD Video Capture Pro
OTHERS	DC adaptor, remote controller, AV cable, Manual

Standards

STORAGE MEDIA	USB Flash Disk, Portable Hard Disk
	Max Capacity: USB / 2T
	Note: The exFAT format is not supported.
RESOLUTION	Input / Pass-through: 720 x 480 (60p), 720 x 576 (50p), 1280 x 720p (50p), 1280 x 720p(60p), 1920 x 1080 (50i), 1920 x 1080 (60i), 1920 x 1080 (24p), 1920 x 1080 (25p), 1920 x 1080 (30p), 1920 x 1080 (50p), 1920 x 1080 (60p)
	Capture: 720 x 480 (60p), 720 x 576 (50p), 1280 x 720p (50p), 1280 x 720p(60p), 1920 x 1080 (50i), 1920 x 1080 (60i), 1920 x 1080 (24p), 1920 x 1080 (25p), 1920 x 1080 (30p), 1920 x 1080 (25p), 1920 x 1080 (30p)
	Note: Up scaling is not supported.
RECORD FORMAT	Video: MP4, Audio: AAC Stereo
RECORD QUALITY	Max: 18Mbps@1080P 30fps
RECORD FILE	Max: 2GB / Per File, With RTC (Real Time Clock)
RECORD PLACE	Max: 140MB / Minute, 8.4GB / Hour
POWER SUPPLY	USB DC 5V / 2A



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE