

USER MANUAL



FOR

EasyBBQ ^{pro}

Smart Wireless BBQ Thermometer

www.pyleaudio.com


Get to know the Device



The device provides 6 sockets for probes, which enable you monitor 6 items at once. If you need more probes besides these 2 probes in the standard package, please contact the dealer.

Put in the Battery

2 AA size battery are needed for this device. Make sure they are put in the right direction by following the icons on the unit.




- 1 Twist the battery cover counterclockwise to unlock.
- 2 Put in batteries, noticing the icons that show directions.



- 3 Make sure the icon ▲ pointing to the icon ■ when you put the cover back; then twist the cover clockwise to lock it, aligning ▲ with ■.

Install the probes

The device will keep scanning the sockets when its power is switched on, the Probe Indicators will blink one by one from 1 to 6 where probes are plugged in. Then insert the probes into the food, make sure the front tip of the probe is in the center of the food to get accurate temperature.



Download the APP

Search the keyword 'easybbq' in Appstore or Google Play, or scan the following QR code with your phone.

Download and install it for free.

Make sure your phone meets the requirements:

iPhone 4S, and later models;
iPod touch 5th, iPad 3rd generations and later models, all iPad mini;
Android devices running version 4.3 or later, with blue-tooth 4.0 module.



EasyBBQ app

Pair with your phone

- 1 Switch on your device and keep the blue-tooth switch of your phone on.
- 2 Launch the app, and follow the instructions in the app to pair and activate the device: Press the Pairing / Stop Alarm Button (in the front of the device). Or, scan the bar code on the package or on the device.
- 3 Connected successfully.

Status Indicator

Blinking Blue

Solid White


Solid Blue

Once Paired the device with your phone, you don't need to do it again, unless you change to other phones.


Enjoy your barbecue time

Choose food type and preference for the food where each probe is inserted, the app and the device will display its current and target temperature.


When the food is ready, the app and the device will alarm.



The user interface of the app may be changed when upgrade. Please follow the instructions in the app.




With the rotatable handle, you could place the device on a table with a comfortable angle or hang it on something.



WARNING

The heat resistance varies in different components of the probe, DO NOT put the probes directly in fire flame. And probes are NOT dishwasher safe.



Operation is Subject To The Following Two Conditions:
(1) This device may not cause interference, and (2) This device must accept an interference, including interference that may cause undesired operation of this device.

App Store is a service mark of Apple Inc.
Google Play is a service mark of Google Inc.



Help and Warranty

Having trouble? Don't return it! We are here to help and make sure you are 100% happy with your purchase!

Reach out via email

askpyle@gmail.com

Or check out our FAQs and resources on the web

www.pyleaudio.com

"Don't forget to register with us online to receive your free 1 year warranty!

www.pyleaudio.com/ProductRegistration.aspx