



# serenelife<sup>∞</sup>™



## ***SLGZX3*** **Foldable 2-Wheel** **Golf Push Cart**

Aluminum Pull Cart, Upper & Lower  
Brackets with Elastic Strap,  
Without Umbrella Holder

## USER MANUAL

### **WARNING:**

- For your own safety, please read and understand these warnings and keep this user guide for future reference.
- Always make sure the trolley is fully extended and locked before use. Always make sure the trolley is folded and locked properly before lifting or transporting.
- Do not run while using this product.
- Do not use accessories other than those designed for use with this trolley.
- Keep all packing materials away from children and recycle where possible or where required by law.

### **MAINTENANCE**

- To clean the trolley, wipe with a soft, dry cloth.
- Car polish may be used to maintain finish.
- Lubricate moving parts every 6 months.


### **WARNING:**

- Keep hands and fingers away from moving or sliding parts!
- Always keep control of the buggy - Do not let it run down hills without full control.




## PARTS LIST


- A** Handle
- B** Scorecard set
- C** Adjustable tube
- D** Fix mechanism
- E** Upper bracket
- F** Sliding lock
- G** Upper frame lock mechanism
- H** Right weight stabilize rod
- I** Left weight stabilize rod
- J** Leg bracket
- K** 2 holes leg frame
- L** 3 Holes leg frame
- M** Right wheel lock mechanism
- N** Left wheel lock mechanism
- O** Rear wheel set
- P** Mainly frame
- Q** Anti-wire
- R** Lower bracket




## ASSEMBLY STEPS




Unfold the upper frame as Fig.1




Take the steel ring to click the groove, then take back the buckle 1 to fix as Fig.2




Press the steel bar to assemble the rear wheel as Fig.3



Open the lower bracket as Fig.4



Release the buckle 2 to pull the upper handle as Fig.5



Open the upper bracket as Fig.6



Complete assembled as Fig.7

## FOLDING




Fig.8  
Fold the upper bracket as Fig.8




Fig.9  
Release the buckle 2 to fold the handle as Fig.9




Fig.10  
Take off the buckle 1 to release the steel ring, then fold the upper and bottom frame as Fig.10/11





Fig.12  
Fold the lower bracket as Fig.12






Fig.13  
Completely folded as Fig.13


## BAG AND CLUB ON THE TROLLEY TO FOLD




**Fig.14**



**Fig.15**



**Fig.16**



**Fig.17**




**Fig.18**

Bag and club on the trolley as Fig.14, release the buckle 2 to fold the upper tube as Fig.15

Take up the slide lock to release the steel tube as Fig.16/17


Completely folded as Fig.18

## DETAILS OF ASSEMBLY



**Fig.19**

Release the bolt to adjust the upper bracket in the middle of the reference line as Fig.19



**Fig.20**

Press the buckle to adjust the height of scorecard holder as Fig.20

## FEATURES:

- New Deluxe 2-Wheel Aluminum 2-Wheel Pull Cart
- Lightweight and Foldable Golf Trolley
- Upper and Lower Bracket with Elastic Strap
- TPE Handle Grip
- Push Button System
- Ergonomic Padded Adjustable Handle
- Simple Quick Braking System
- Durable and Compact Size for Easy Storage and Transportation
- Easy to Fold and Unfold
- Designed for Multiple Pushing Positions
- Umbrella Holder Not Included
- \*Assembly Needed

## WHAT'S IN THE BOX:

- (1) 2-Wheel Golf Push Cart

## TECHNICAL SPECS:

- Construction Material: Aluminum Frame
- Max. Load Capacity: 33 lbs.
- Rear Wheels Size: 9.5" -inches
- Folded Product Dimension (L x W x H): 19.1" x 14.6" x 22.8" -inches
- Unfolded Product Dimension (L x W x H): 44.7" x 28" x 47.8" -inches



serenelife™

