

# SLIB950 - SLIB960 - SLIB970 Inflatable Jumping Castle

Indoor/Outdoor Portable Bounce House with Mini Slide for Kids

serenelife™

**USER GUIDE**

## **WARNING**

To reduce the risk of serious injury or death, read the following important precautions before using the *SereneLife Inflatable Jumping Castle*.

## **Precautions**

- Ensure electrical source is safe and stable before operation.
- Keep children away from blower. Do not insert fingers, toes, etc into the blower, or it may cause injury. Do not insert foreign objects into the blower. This will cause damage.
- Do not bring sharp objects into play area.
- Do not eat in play area.
- Do not smoke in play area.
- Keep product away from fire and heat.
- In case of blower malfunction, tighten blower vent and evacuate play area immediately.
- Do not use in rain, strong wind or extreme weather conditions.
- Observe precautions on product WARNING LABEL at all times.

## **Setup**

- Unroll product evenly across smooth, flat, debris-free surface. Connect blower(s) to inlet, and tie. Anchor the blower to the ground using the stakes provided.
- Plug in and start blower.
- If your item uses multiple blowers, connect all blowers to their inlets. Make sure all blowers are powered off (blower models with switch). Plug in all blowers, then switch them on one-at-a-time at 20 second intervals.
- Once inflated, anchor the inflatable product to the ground using the stakes provided.

## **Disassembly**

- Ensure that all the players have left play area.
- Remove any loose articles or debris from play area.
- Turn off, and unplug blower.
- Once product is fully deflated, fold & store in cool, dry area.

## **Maintenance & Repairs**

- Always keep products clean to protect the seams and surface.
- Regularly inspect seams and play surface for any necessary repair. Slight damage caused by nature or man-made factors can be repaired with the repair kit provided.
- To repair, deflate the product thoroughly, and ensure surface is dry. Cut patches to sizes suitable for repair. Apply glue on both the repair patches, and the damaged surface. Allow the glue to air-dry for 30 seconds before adhering the patch to the play surface. Allow to dry for at least 4 hours before use.



SLIB950



SLIB960



SLIB970

## **Questions? Issues?**

We are here to help!

Phone: (1) 718-535-1800

Email: [support@pyleusa.com](mailto:support@pyleusa.com)