

serenelife

Infinity

All models:



SLT502 SLT513 SLT524 SLT535 SLT546 SLT557 SLT568 SLT579 SLT585 SLT598



Questions? Issues?
We are here to help!
Phone: (1) 718.535.1815
Email: support@pyleusa.com



serenelife

Lightweight and Foldable
Kick Scooter

Adjustable Scooter for Teens and Adult,
Alloy Deck with High Impact Wheels

OWNER'S MANUAL

Please take note of the following points in order to ensure the continuous enjoyment of this product. Please read this owner's manual carefully before use. The owner's manual as well as the packaging are constituent parts of the product, both should be stored for future issues. This product is not intended for commercial use, the use requires specific knowledge and skills. This product should only be made available to a user of an appropriate age and should only be used for its intended purpose. The assembly has to be carried out by an adult.

FEATURES



FOR YOUR SAFETY: TO OPEN & CLOSE YOUR SCOOTER

Keep the base of the scooter steady. Open the quick release lever. Slide the red folding button upward while pulling on the handle.



ASSEMBLY:



Step on the lever



Unfold the scooter



Assemble the handle bars



Lock the top clamp



Adjust the height after unfolding the clamp, if the screws are loose, tight it



Unfold completely

FOLDING:



Lower the height of the handlebars by tightening the clamp



Unfold the top clamp, and press the button to separate the handles



Assemble the handle bars



Fold completely

WARNING: RISK OF ACCIDENT AND INJURY!

Using this product carelessly or incorrectly may lead to serious or even fatal accidents and injuries. Please observe the following instructions to prevent injuries and accidents.

- Always check your scooter before using it and ensure that all catches, levers, nuts and screws are tightened properly.

Also make sure that the wheels are properly attached and show no signs of wear, and that the steering shaft is securely fixed at the desired height. Before each use, check that the direction is set properly. Have regular maintenance carried out by a specialist dealer.

- Always wear an approved helmet when using the scooter and tighten the chinstrap.



Always wear wrist protection, elbow pads, knee pads and closed shoes with rubber soles.

- Avoid steep descents as the built-in brake will not provide reliable protection in this case. This brake is not intended for rapid descents!
- The brake pad/disc brake heats up a lot.

Avoid touching it after braking to avoid the risk of burns.

Avoid using the brake in a prolonged and continuous manner.



Be careful not to catch your fingers when folding and unfolding the scooter.

Children are only permitted to use the scooter under adult supervision.

- Pay particular attention to your fingers when using the folding system.
 - Do not exceed speeds of 10 km/h (6.2 mph).
 - Avoid roads, routes and other areas where motor traffic is present.
 - Always follow the highway code.
 - Only ever use the scooter individually.
 - Using the scooter at dusk, at night or when visibility is reduced is very dangerous and increases the risk of accident and injury.
- Never use the scooter at dusk or at night.
- Do not use the scooter on damp, oily, sandy, muddy, icy, rough or uneven surfaces.
 - Do not perform tricks- adapt your use to your personal capability.
 - Always use the feet to step on brake during riding the scooter.
 - Always wear shoes during riding the scooter to avoid injuries.
 - Do not make any modifications to your scooter that may endanger your safety.
 - Do not exceed a maximum weight of 100 kg.
 - Fastening products can become less effective after several months.



MAINTENANCE:

- Clean the scooter with a soft, damp cloth after each use. Clean the wheels regularly with a damp cloth, oil them at regular intervals and replace them as required depending on their level of wear.
- Do not make modifications to the scooter that have not been recommended beforehand.
- Check all screws at least every 3 weeks and tighten them. Always use thread-locking fluid.
- Spray all moving parts of the folding mechanism with penetrating oil at least every 3 weeks and wipe them afterwards.
- Check the headset (steering shaft bearing) at the end around every 4 weeks and adjust if necessary.

WARNING: RISK OF SUFFOCATION!

The scooter contains small parts that can be swallowed. Do not let children play with the packaging or small parts. Children may become entangled and suffocate when playing with these or may swallow small parts and choke on them.

- Only adults are permitted to assemble this scooter.



WARNING! RISK OF DAMAGE!

Incorrect assembly can lead to instability and malfunctions

- Only use the scooter when the handlebar shaft is completely inserted. To do so, please follow the assembly instructions for the corresponding model.
- Never place all your weight on the handlebars as the shaft may bend and you may no longer be able to adjust the height.

WARNING:

- Keep fingers clear of the pivoting mechanism when folding or unfolding the scooter. Make sure others are standing clear.

LAWS AND REGULATIONS

• CHECK LOCAL LAWS REGARDING SCOOTER USE.

Check local laws and regulations to see where and how you may use your scooter legally. In many states and local areas scooter riders are required BY LAW to wear a helmet. Check local laws and regulations regarding laws governing helmet use and scooter operation in your area.

WARNING: ALWAYS INSPECT SCOOTER PRIOR TO RIDING.

- Properly inspecting and maintaining your scooter can reduce the risk of injury.
- Always inspect your scooter before riding and regularly maintain it.
- Check and secure all fasteners before every ride. Replace worn or broken parts immediately.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS FURTHER INCREASES RISK OF SERIOUS INJURY. USE AT YOUR OWN RISK AND WITH APPROPRIATE AND SERIOUS ATTENTION TO SAFE OPERATION. USE CAUTION.

NOTE:

Manual illustrations are for demonstration purposes only. Illustrations may not reflect exact appearance of actual product. Specifications subject to change without notice.

FEATURES:

- Compact Kick Scooter
- Lightweight Alloy Deck
- Smooth Riding Wheels
- Comfortable T-Bar Handlebar
- Durable ABEC-7 Bearings
- T-bar Anodized Clamp Collar
- Includes Extended Standing Area for Pro-style Scooter Performance
- Stand Kick Scooter Design with Rubber Grip at Tip
- Adjustable T-Bar Handlebar Height
- Long-Lasting, Super Smooth Gliding Wheels
- Easy Maneuvering
- Lab Tested & Safety Certified
- Indoor/Outdoor Use
- Suitable for Teenagers and Adult, Beginner and Intermediate Riders
- Long Guard Rail to Stop Easily
- Mud Guard Front Wheel
- Extended up to 3 Heights
- Easy Folding Technology
- Foldable Handles
- Non-Slip Rubber Deck + Foot Stand
- Front Suspension
- Easy Open and Close
- Red Flashing Light

WHAT'S IN THE BOX:

- (1) Teens Scooter
- (1) Simple Tools for Assembly
- (1) Carry Strap
- (1) PE Warning Bag
- (1) LED Back Light

TECHNICAL SPECS:

- Construction Material: 20% Steel + 80% Alloy
- Wheel Type/Wheel Material: PU Wheel
- Recommended Age: 8+
- Weight Capacity: Up to 220 lbs.
- Handlebar Height Setting: 35.04" x 37.20" x 38.9" -inches
- Wheel Size: 8" -inches
- Deck Size: 22.44" x 4.80" -inches
- Folding Size: 31.89" x 4.92" x 12.72"-inches
- Unfolding Size: 36.02" x 18.5" x 38.9" -inches
- Total Scooter Size (L x W x H): 36.6" x 18.9" x 38.8" -inches



WARNING:

This product can expose you to a chemical or group of chemicals, which may include "Carbon black" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.