



# POLYRESIN LED TABLETOP FOUNTAIN



## HOW TO INSTALL:

1. Connect the water-pipe and pump. See picture 1
2. Place the pump into the fountain .
3. Fill the fountain with water and make sure the pump is submerged with water
4. Plug it in to an outlet to power it ON



Be careful not to spill water onto the plug of the pump.  
**DO NOT** allow the pump to run dry!

## TROUBLESHOOTING:

### 1. If your fountain pump fails to operate please check the following:

- Make sure the pump is plugged into the socket properly.
- Check the water level in the fountain. Running the pump without sufficient water can damage the pump.
- Check the setting of the flow control on the pump. See picture 2. Check the pump outlet nozzle and the water tube for dirt and debris. Clean if necessary.
- Make sure the pump is connected to the water tube tightly. Check the fountain tubing for kinks and obstructions
- The pump may be "air locked". Plug and unplug the pump several times to clear any air that may have been trapped.

### 2. If the water does not flow out of the fountain, it may be caused by kinked or loose water tubes, make sure water tubes are properly connected.