


# Tabletop Water Fountain



## SETUP INSTRUCTIONS:

1. Ensure the water flow pipe and LED light cable is connected securely at the bottom of the fountain.
2. Add water to the bowl and plug in the power supply.
3. There should be enough water in the fountain tray so that it covers the water pump.



Power of pump can be controlled

\*Water flow pressure/intensity can be controlled with the adjustable power level located on the pump



Be careful not to spill water onto the power plug of the pump.

**DO NOT** allow the pump to run dry or with an inadequate amount of water!

## TROUBLESHOOTING:

### 1. If your fountain pump fails to operate please check the following:

- Make sure the pump is plugged into the wall outlet/socket properly.
- Check the water level in the fountain. Running the pump without sufficient water can damage the pump.
- Check the power switch of the flow control on the pump. See picture 2 above.
- Check the pump outlet nozzle and the water tube for dirt and debris. Clean if necessary.
- Make sure the pump is connected to the water tube tightly. Check the fountain tubing for kinks and obstructions
- The pump may be "air locked", Power the pump ON & OFF several times to clear any air that may have been trapped.

### 2. If the water does not flow out of the fountain, it may be caused by a kinked or loose water tube, make sure the water tube is clear of any obstruction and fitted properly.