

PWMA50B

Compact & Portable Waist-Band PA Speaker System
Voice Amplifier & Microphone Headset with Built-in Rechargeable Battery

PYLE

PyleUSA.com

User Manual

Battery Charging:

The battery requires charging if the unit's LED indicator light is dim or off. To charge properly and optimally, power off the unit and then insert the power adapter into the charge port. When the unit is fully charged, the LED indicator light will shine green (while the unit is not fully charged, the LED indicator light will shine red).

Microphone:

The headset microphone is to be worn as indicated in the picture. Suitable distance between the mic and mouth is about 20-30 millimeters. The mic connects to the input of the voice amplifier.

Operation:

Turn the rotary control knob clockwise to power on the unit. Then, the LED indicator light will activate, indicating the amplifier is ready for use. Adjust the rotary volume knob accordingly --lowering the volume may result in a cleaner and noise-free audio experience.

Notes:

Average charging time can range from 3-4 hours. If the battery efficiency or effectiveness seems to function less than optimally, contact customer service. Ensure the microphone headset cable is inserted into the correct input (the mic should be connected to the input labeled "Mic").



Features:

- Compact, Portable & Powerful
- PA Speaker Amplifier Projects Your Voice
- Includes Headset Microphone
- Used for Karaoke, Crowd Control, Presentations
- Built-in Rechargeable Battery, Up to 8+ Hour Life
- Aux (3.5mm) Input & Microphone Jack
- Connect & Stream Audio from External Devices
- Rotary Volume Control

What's in the Box:

- Compact PA Speaker Amplifier
- Headset Microphone
- Power Adapter
- Waist-Band Strap
- Belt Clip

Technical Specs:

- MAX Power Output: 50 Watt
- S/N Ratio: 53dB
- Built-in Rechargeable Battery: 7.4V Lithium, 1600mAh
- Headset Microphone Cable Length: 3.3' ft.
- Power: 110/240V
- Dimensions (L x W x H): 3.9" x 1.8" x 3.6"



Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com