

HURTLÉ
PYLE



HURVBTR63

Standing Vibration Fitness Machine
Vibrating Platform Exercise & Workout Trainer

USER MANUAL

**PLEASE READ THIS MANUAL CAREFULLY BEFORE USE
AND KEEP IN A SAFE PLACE FOR FUTURE REFERENCE**

IMPORTANT SAFEGUARDS

When using electrical appliances basic safety precautions should be followed, including the following:

- Read all instructions carefully before using the appliance and store in a safe place for future reference.
- Check the voltage on the rating plate corresponds with your supply voltage before plugging the appliances in.
- Use this appliance only for its intended use as described in this manual.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience or knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure they do not play with the appliance. This product is not a toy.
- Do not operate the appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person.
- Do not use the unit if the inner components of the machine are exposed or the wires are broken.
- Do not use in electrical storms or power surges
- This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- Do not allow the power cord to come into contact with hot surfaces or become tangled or knotted. Do not run the mains power cord under heavy objects
- Do not wrap the mains cord around the unit.
- Do not insert objects into the holes or slots in this appliance.
- Do not operate this appliance with wet hands or feet.
- Do not use the product on uneven, moving or unstable floor surfaces.
- Install or locate this appliance only in accordance with the installation instructions provided.

- Do not use this product near water, in a damp environment or in an environment where there is high humidity
- Do not immerse the product or the power base in water or any other liquids.
- Do not store or use this appliance outdoors
- Do not allow water to get on to the electrical connections.
If the connections get wet, unplug from the socket immediately and dry thoroughly before use.
- This appliance contains no user serviceable parts. Repairs should only be carried out by a qualified service engineer.
- Unplug the appliance from the socket when not in use.
- When removing the plug from the mains power supply, do so by holding the plug tightly. Do not remove by pulling the mains p power cord.
- Keep the area around the product free from obstructions.
- This appliance is intended for household use only.
- Do not touch the power cord or appliance with wet hands.
- Do not plug into a socket where several other appliances are plugged in.

This product has not been designed for any uses other than those specified in this booklet.

HEALTH CONDITIONS


If you / the user have suffered from any of the following conditions you must obtain your doctor's permission before using the product:

- brain hemorrhage
- Congenital heart disease
- Backbone deformities or brittle bones
- Fractured bones or joints
- Pregnancy
- Recuperation from an operation or illness
- Mental disorders
- Acute illness such as cancer or terminal illness
- Contagious skin diseases

IMPORTANT NOTES:

- Always select the appropriate level of training for your own personal fitness
- Clean the unit after each use with a damp cloth – do not use harsh or abrasive cleaners
- Always inspect the unit for wear and tear after each use
- Ensure the switch on the control panel is turned off after each use and the appliance is switched off and unplugged at the mains
- Store the product in a clean, dry place when not in use

ASSEMBLY



INSTRUCTIONS FOR ASSEMBLY

- Remove your product from the box taking care not to scratch the surface of the machine.
- Remove any packaging from the product
- Place the packaging inside the box and store for future reference
- Feed the signal wire from the lower aluminium column into the branch pipe of the base section (casing) and connect to the signal port (see picture 1).
- Align the hole in the lower aluminium column with the hole in the branch pipe of the base section (casing) and use and M6 x 40mm locknut to secure in place (see picture 2).
- Place the armrest and control panel section onto the upper aluminium column aligning the holes in both sections (see picture 3).
- Fix the armrest and control panel in place using the threaded rod (see picture 4).
- Extend the upper aluminium column and secure in position using 2 x M6 x 40mm lock nuts and plastic gaskets (see picture 5).



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5

INSTRUCTIONS



Put the power cord inside the power outlet of the product, buzzer "beep", digital tube and LED lights all bright, one second after the switch to standby. In standby mode, neither the digital nor the LED lights are displayed. Press the **START/STOP** key, the machine enters the working state, press the **START/STOP** key in the working state, the machine re enters the standby state.

In the working state, the machine enters the manual mode, has the corresponding pattern lamp instruction, the initial running time is 10 minutes, may pass the time key to carry on 1-15 minutes set. The initial speed is 1, and the speed is set at 1---15 by adding and decelerating keys.

In the working state, according to the mode switch key, you can set the mode of operation, namely manual - Automatic 1 - Automatic 2 - Automatic 3 - automatic.

In auto mode, the speed add and subtract keys and time keys are not valid. Auto timer is 10 minutes. From the automatic 4 to the manual, the running time and speed are the same as the current.

Four automatic modes: 0

Automatic 1: movement track: within 10 minutes, from 1 files per second to 15 stalls, and then from 15 to 1 files per second. Return 0

Automatic 2: movement track: within 10 minutes, every 5 seconds from 1 to 15 stalls, and then every 5 seconds from 15 to 1 files. Return

Automatic 3: movement track is: 10 minutes, the direction is always increasing, every 1 second by a file, to 15 files, change 1 files.

Automatic 4: movement track is: 10 minutes, every 3 seconds, 1 stalls, ---10, ---5,--15, four stalls jump.

SUGGESTED EXERCISES



Straight Posture

Stand on the massage plate with feet apart. Hold the handle and stand straight. Exercises the back, waist, buttocks, chest and abdomen.



Ride Posture

Stand on the massage plate and hold the handle. With knees bent, place feet apart at a distance a little wider than the shoulders. Exercises the buttocks, thighs and calves.



Tiptoe Posture

Position as 'ride posture' but on tiptoes. Exercises the feet, buttocks, thighs and calves.



Runaway Posture

Bend over placing hands on either side of the massage plate and bending knees as if ready to run. Exercises the shoulders, back, arms and chest

CLEANING AND MAINTENANCE

- Always turn the appliance off and disconnect from the mains supply before cleaning.
- Wipe the unit with a soft, damp cloth and dry thoroughly. Do not use harsh or abrasive cleaners.
- Do not use a damp cloth on the control panel or handle but wipe carefully with a soft, dry cloth.

TROUBLESHOOTING

FAULTY	CAUSE	SOLUTION
Machine will not function	Check if the machine is plugged into the mains and switched on	Insert power plug into the mains socket and switch on
Machine will not start	Check if the emergency insert is located correctly	Insert emergency stop key into the socket

FEATURES:

- Revolutionary Vibrating Design for Fitness that's Fun!
- Vibration Assisted Exercise for Full Body Training
- Excellent Toning for Abs, Thighs & Buttocks
- Total Body Fitness: Incorporate Upper Body, Lower Body & Core Workouts
- Simple Electronic Plug-in Design
- Easy Operation: Stand On & Power On
- Digital LCD Display with Touch Button Controls
- Adjustable Time & Speed Settings
- Dynamic Oscillating Motion Technology
- Accelerated Fat Burning & Weight Loss
- High-Powered Vibrations do the Hard Work
- Lab Tested to Improve Muscle Strength, Flexibility & Circulation
- Reduce Appearance of Cellulite, Improves Metabolic Rates
- Comfort Grooved Rubber Base Foot Pad
- Ideal for All Body Types & Age Groups
- Convenient Base Wheels for Quick Setup & Storage
- Perfect for Sports Training, Weight Loss, Burning Fat

TECHNICAL SPECS:

- Power Output: 500 Watt
- Revolutions per Minute: 550 RPM
- Vibrate Session Time Settings: Up to 15 Minutes
- Adjustable Vibration Speed Settings: (5) Selectable Mode
- Load Capacity: 264 lbs. Max.
- Power: 120V
- *Some Assembly Required
- Construction Material: Reinforced Aluminum Alloy, Engineered ABS
- Total Assembled Dimensions (L x W x H): 21.2" x 19.7" x 46.0" -inches
- Sold as: Unit

HURTLÉ



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

PyleUSA.com/ContactUs

PYLE