

# FRONT



# BACK



#### BEFORE USING:

- Before using your glass food container for the first time, remove all packaging, stickers and labels from the product and store or dispose of safely.
- Wash thoroughly with a mild detergent, rinse and dry.
- During the first few uses, you may experience a gasket ejection or it may be difficult to open the lid because the 100% airtight function. This is not a manufacturer's defect.

#### CLEANING:

- Top rack dishwasher safe on delicate / low cycle to prevent damage.
- When hand washing, to preserve clarity and shininess of your glass food container, do not use abrasive cleaners or scouring pads.

#### CAUTION: USE IN MICROWAVE OR OVEN

- To use in microwave or oven, please do follow the directions in the user manual to avoid breakage of the container.
- Do not use on direct fire and the lids cannot put in the microwave or oven.
- Do not close the lids when heating, it may cause breakage of the container.
- Do not overload when using in microwave.
- Do not directly heat up the frozen contents with in the container.
- Do not heat highly oiled substances, it may cause breakage of the container.

#### CAUTION: STORAGE IN FREEZER

- When frozen, substances might expand and cause potential breakage of the container.
- Do not fully fill up with water or liquid. Recommended capacity is less than 80% of full level.

#### CAUTION: USE OF GLASS CONTAINER

- Carefully check for any scratch or crack before use.
- Even a tiny scratch may cause breakage.
- Frequent impacts on the container may cause breakage.
- Any scratch from abrasive cleaners may cause potential breakage.
- Do not pile up the container without plastic lids.
- Sudden temperature changes may cause disfiguring or breakage of the container.

#NutriChefKitchen



Questions/Concerns: [jb@pyleusa.com](mailto:jb@pyleusa.com)