



PCS2X4 Center Channel Speaker

with Dual 4-Inch Wooden Woofer and Silk Dome Tweeter




To ensure you will be completely satisfied with this product, read and understand this manual carefully before use. Keep the manual in a safe place. The Operating Manual must be passed on to all subsequent users.

Safety Instructions

- 1. Please read the instructions carefully before installation and use. Keep the manual safe for future reference.
- 2. To prevent fire or electricalshock, do not expose the speakers to rain or water.
- 3. To prevent the endosure from warping or discoloring, do not place the speakers where they will be exposed to direct sunlight or excessive humidity.
- 4. Damage to the woofer and tweeter may occur if the speaker is dropped or hit resulting in no sound or distorted sound.
- 5. Use only approved and certified wiring in your installation, do not stretch or place the wire in contact with sharp objects.
- 6. Make no modifications to the speakers or accessories. Unauthorized alterations may compromise safety, regulatory compliance, and system performance.
- 7. This product must be used indoors. It is neither designed nor tested for use outdoors.

Packing List

Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.





User Manual

Speaker and Speaker Cable

Technical Specs:


- MAX Power: 100W
- RMS Power: 40W
- Impedance: 8 Ω
- Sensitivity(1M/1W): 84dB
- Frequency Response: 60Hz-20kHz
- Woofer Type: 2x4" Polypropylene cone with rubber edge
- Tweeter Type: 0.75"(20mm) Silk dome tweeter
- Crossover Slope: 12dB/Octave
- Cabinet Material: MDF with Vinyl Finish
- Overall Dimensions: 6.3X 15.7 X 8.6-inches

Placement Guidelines

This speaker can be used mutlifunctionally as a bookshelf speaker, surround speaker (satellite) or center speaker. Please refer to the pictures below for individual set-up options:

Main Left and Right Channels

Position the speakers on both sides of the TV.





Surround Left and Right Channels

When using the speaker as rear channel speakers in a home theater application, they should be placed to the side and slightly behind the listening position.

Center Channel


When using the speaker as a center channel speaker in a home theater application, locate the speaker as close to the center of your TV or monitor as possible





Connections

Always check to ensure polarity is correct.




Note:

- 1. When using an amplifier with a rated output power higher than the nominal input power of the speakers, care should be taken never to exceed the speakers' maximum input. This speaker is compatible with 4- or 8-0hm audio amplifiers.
- Anytime you note distortion, reduce the volume controlon your amplifier to a lower setting. Never allow your amplifier to be driven into "clipping".
 Otherwise the speakers may be damaged.

Care and Maintenance

- 1. Disconnect the wiring to the speaker when unused for long periods of time.
- 2. Ensure all equipment is turned off prior to cleaning.
- 3. Front cover requires only occasional dusting.



The front cover is fastened to the enclosure at four points.


To remove the cover, grasp both sides and slowly pull straight away from the speaker.

To reattach, line up the four pegs on the inside surface of the cover with the four corresponding holes on the speaker and push gently.

Tips:

When the cover is removed, take care not to touch the speaker drivers with your hands or to exert excessive force with tools.

Do not attempt to clean the speakers with chemical solvents as this might damage the finish. Always clean using a dry cloth.







Questions? Issues?

We are here to help! Phone: (1) 718-535-1800 Email: support@pyleusa.com