

SereneLife



SLSWNG100

Heavy-Duty Steel Tube Fabric Swing
Indoor/Outdoor Fabric Swing for Children
with Adjustable Rope and Padded Steel Tube - Black

Safety and Assembly Instructions

IMPORTANT

**READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS.
KEEP FOR FUTURE REFERENCE**



WARNING! CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS. **WARNING!** MAXIMUM WEIGHT SHOULD NOT EXCEED 400LBS.

WARNING! DO NOT USE WITHOUT ADULT SUPERVISION!

WARNING! ADULT ASSEMBLING REQUIRED!

ESSENTIAL INFORMATION

- Recommended for children 3+ years
- Do not leave child unattended while in use
- **CAUTION:** Use only under adult supervision
- Good safety practices should be followed at all times
- Read all instruction before using this product.

Hanging hardware not included. Ideally, the swing body should be hung over grass, sand, wood chips, or other soft surfaces.

Under no circumstances should it be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 15.7 inch; the maximum fall height should not be more than 18 inch, Two S hooks are attached to the rope to allow for adjustment of the rope length. Please be sure to examine the ropes regularly. If the color of the rope has become pale, frays easily, or gives off a powdery material when rubbed between the fingers, we

recommend you replace the rope. Equipment should be hung in such a way that a distance of at least 6.56 ft is clear on either side. Can be hung on an A-frame or swing set or on a tree limb of a diameter of at least 9.84 inch.


WARNING! Small parts for assembly by an adult.

You may also follow the SereneLife Set Up Instructions Video For Spider Web Tree Saucer Swing: <https://youtu.be/XRoeWAHdOHA>

Tools Required (included in the packaging)



Assembling Steps




1. Swings arrives in 4 pieces, and 2 hanging ropes, a jump body for assembly.




2. Put the jump body on the floor, and put the 4 section to the black mat direction



3. Put the 4 metal tube with foam into the sleeves one by one




4. Put the tube



5. Put 2nd tube to the sleeve, small socket to the big socket of the 1st. tube, and connect it.



6. Repeat it, and make it like half folded as the pic.



7. Then connect the body as a round platform.




8. Assemble the screw bolt, first put it through the velcro belt.



9. Screw bolt go through the velcro belt cover.



10. Assemble the screw bolt to the frame tube.



11. Tight it with screw nut, do not forget the washer.



12. Use wrench tight it before use.



13. After the bolt assembling, and cover the velcro belt, and repeat 3 times on other 3 bolts.



14. Top looking and appearance



15. Assemble finished, and ready for swing.

Ensuring Safety of the Swing

Clearance distance should be 13 ft around the swing. Do not use the equipment until properly installed. This swing is not to be used in any other manner other than its intended use. Adult supervision is required. Adults should verify that the hanging ropes are secured and cannot be looped back on the swing.

It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that is potentially hazardous).
- Sit on the center of the swing with full weight on the seat if swinging alone.
- Avoid swinging empty seats. It is important for adults to instruct children

NOT to

- Walk close to, in front of, behind, or between moving items.
- Twist ropes or loop them over the top support bar since such action may reduce the strength of the rope.
- Get off the sing while it is in motion.
- Climb on the swing when it is wet.
- Attach additional items to the swing that might cause a strangulation hazard.
- Wear a bicycle or sport helmet while on the swing.

Maintaining the Swing

At the beginning of the each play season, adults should:

- Tighten all hardware.
- Check all protective coverings on pipes, edges, and corners, Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seat, ropes for wear, rust, or other deterioration. Replace as needed. The hardware used for this swing (binding post, screw, S hook, lock washer, flat washer, and metal ring) can be found at local hardware store.
- Check metal parts for rust, if found, and repaint using a non-lead-based paint meeting the ASTM requirements.

- If the swing is hung from swing set frame, then lubricate all metallic moving parts, that are attached by a metal connection.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth (Min amount is 9.84 inch), replace as needed.

Twice a month during pay season, adults should:

- Tighten all hardware
- Check all protective covering on pipes, edges and corners. Replace if they are loose, cracked, or missing.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth (Min amount 9.84 inch) Replace as needed.

Once a month during play season, adults should:

- Check all moving parts including ropes for wear or other deterioration. Replace as needed.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth (Min amount 9.84 inch) Replace as needed.

At the end of each play season, or when the temperature fall below 39.2 °F adults should:

- Remove the swing from its outdoor location.
- Store the swing in a dry environment.

Disposing of the Swing

To dispose of the swing, first disassemble it, Dispose of it in such a way that no unreasonable hazards will exist at the time that the swing is discarded.

This confirms to ASTM, Consumer safety performance specification for home playground equipment.

SLSWNG100

Heavy-Duty Steel Tube Fabric Swing Indoor/Outdoor Fabric Swing for Children with Adjustable Rope and Padded Steel Tube - Black

Features:

- Large Heavy-Duty 40-Inch Diameter Fabric Swing Base
- Set-up Indoor/Outdoor (Requires Assembly)
- EPE Foam Padded Steel Tubes Protect Against Pinching
- Durable Fabric Cover Provide Comfort and Ventilation
- Built-in Steel Hooks for a Safe and Secure Ride
- Portable and Easy to Assemble
- Large and Comfortable Swing with Adjustable Rope
- Perfect for Sitting up, Laying on Stomach and Back
- Take Your Child to the Next Level for Fun and Excitement

What's in the Box?

- (4) Curved Steel Tube Sections with Foam Padding
- (2) Adjustable Rope
- EPE Foam Tube
- Swing Base
- Mini Wrench
- Manual

Specifications:

- Material: 600D Polyester Oxford
- Base Size (D): 40.0" -inches
- Material of Rope:
- Rope Length: 5.25ft
- Rope Thickness: Dia 10mm
- Steel Tube Size: 0.98" x 0.031" -inches
- EPE Foam Tube: 1.02" x 0.31" -inches
- Weight Capacity: Up to 600 lbs.
- Sold as: 1



SereneLife

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com

