Attentions:

- When connect the electric power wires, you should make clear about the
 positive and negative electrode (the red one is positive and the black
 is negative). If you wrongly connected the fuse in the filter box will be
 broken protectively. Please replace the fuse in same parameter.
- 2. Because the LCD screen is the main component. It should be paid attention to be damp-proof.
- 3. The device must be installed firmly to prevent falling of device that will possibly cause injury and device-broken.
- 4. The connecting-point of direct current (12V) should connect on the Main line of storage battery as possible as it can, for keeping this device in normal operation and be away from the large voltage drop influence.
- 5. There is high voltage cluster in this machine, if you are the professional person, should never to take part the machine if malfunction and contact the dealer in time.

Accessories

1 x bracket

1 x headrest shroud

1 x remote control

1 x instruction manual

2 x connection wire



Instruction Manual

PLVHR75





7" Widescreen TFT/LCD Video Monitor w/Headrest Shroud and Stand Thank you for purchasing the TFT LCD color monitor. To enjoy the features of this device and to ensure years of trouble-free operation, please read this manual carefully and follow the instructions.


Front Panel



- 1. Power ON/OFF
- 2. V1/V2 switch
- 3. Activation of menu indicator
- 4. Negative adjustment

- 5. Remote sensor
- 6. Positive adjustment
- 7. 16:9/4:3 display switch
- 8. Image rotation

Remote control



Specification

Screen Size: 7 inch

Resolution: 1440xRGBx234


System: NTSC/PAL Power source: DC 12V

Power consumption: <9W

Video Input: Composition video signal

Operating Temperature: $0^{\circ}\text{C} \sim 60^{\circ}\text{C}$ Storage Temperature: $-20^{\circ}\text{C} \sim 80^{\circ}\text{C}$

Headrest bracket



Installation Diagram

