

3 in 1 Toddler Bike

for 10 Month to 3 Years Old Kids, Convertible Trike
Adjustable Seat and Removable Pedal

User Guide

Before assembling this product and/or giving it to a child, please read all instructions. This guide will walk you through the functions, usage, and proper care of the **Hurtle 3 in 1 Toddler Bike**. Contact your local dealer or distributor immediately regarding any defects or damage.

MAINTENANCE

All of the screws, clamps, and other hardware or plastic parts on the **Hurtle 3 in 1 Toddler Bike** should be inspected periodically to ensure that they are secured properly and not damaged or malfunctioning.



1. The **Hurtle 3 in 1 Toddler Bike** can be cleaned using mild household soap or detergent and warm water on a sponge or clean cloth. Always allow to completely air dry before using the Toddler bike.
2. Lubricate the axle and rotating parts regularly, it will expand the product lifespan.
3. Please regularly check and make sure the screws are not loose and components are not damaged. Remember to replace damaged screws and components.
4. If you need to dismount the bike for transportation or storage, please make reference to manual instruction and use anti-shock materials to protect it.
5. Please make sure the trick handle and saddle junction are tightened, make sure the tightening torque is more than 15 N.M



⚠ SAFETY INFORMATION & WARNINGS

1. Kids should be supervised at all times by a parent or guardian while riding the **Hurtle 3 in 1 Toddler Bike**.
A responsible adult must inspect the bicycle prior to use, to ensure that all parts are fully assembled and tightened to prevent accidents.
2. Age-appropriate protective gear, including helmet, elbow pads and knee pads, must be worn at all times.
DO NOT ride barefoot or in sandals.
3. The **Hurtle 3 in 1 Toddler Bike** is designed for children ages 10 months to 3 years old.
4. Keep away from fire.
5. In order to avoid suffocation, please keep the plastic cover (tape) away from the baby.
6. **DO NOT** place any load on the **Hurtle 3 in 1 Toddler Bike**, otherwise it will affect the stability of the bicycle.
7. Ensure that the handlebar is securely fixed by turning it left and right, and that the wheels spin smoothly, before riding the bicycle. Make sure all components are securely fixed and assembled correctly before riding.
8. **DO NOT** use the **Hurtle 3 in 1 Toddler Bike** near stairs, thresholds, and steps. **NEVER** play near heaters and stoves.
The use of the bicycle is forbidden on roads used by vehicles and on all public roadways in general.
9. Ride the bicycle only on flat and level ground. **DO NOT** ride the bicycle on slopes.
DO NOT go down a long descending slope or hill. Please be careful when passing these areas.
10. The child shouldn't spend more than one hour each time in a continuous ride, the maximum load of the bike is 80 lbs. **NEVER** allow more than one child to ride on the bicycle at any time.
11. The saddle must be locked in place before using to avoid accidents.
12. Adult assembly is required for this product.
13. **DO NOT** ride the bicycle with one or no hands. Hold the handlebars tightly with two hands.
14. The bicycle should be used with caution since skill is required to avoid falls or collisions causing injury to the user of third parties.


3 IN 1 TODDLER BIKE PRODUCT PARTS




ASSEMBLY INSTRUCTIONS

Caution: Make sure the rear leg is fully opened after assembling the bike, otherwise the bike may become unstable. This bike must be assembled by adult to make sure it's assembled in the correct manner before using.

Step 1: Install the fixture 2 into the front wheel tube 1.




Step 2: Pass the Front wheel tube 1 assembly through the Bike frame 3 head tube.





Step 3: Insert the handlebar 4 into the front wheel set, mind to align with the notch and hole of the stand tube, and then fit through the screws 5 and tighten using a screw driver.



Step 4: Insert the Pedal 7 into the front wheel. Insert the Frame fastener 8 near the seat tube of the main frame.



Step 5: Finally, insert the saddle **6** into the seat tube of the mainframe, and then use a screw driver and pliers to lock up the saddle clamping head to ensure that the saddle clamping head doesn't rotate.






HOW TO FOLD

Step 1: Press the white button on the rear leg to rotate the left/right rear wheel inward in place.

Step 2: Pull out the Frame fasteners

Step 3: Hold and press the frame button to close the rear leg, make sure the rear leg is closed fully.

Step 4: Insert the Frame fasteners into the rear leg.



Features:

- For 10 Month to 3 Years Old Kids
- Different Styles for Boys and Girls
- Three Mode Suitable for Growing with Baby
- Easy to Assemble and Convert to other Mode
- Steel Bike Frame and Durable Widen Silent Wheels
- Safety and Comfortable Design
- Adjustable Seat Height
- Removable Pedals
- Perfect Gift for Christmas or First Birthday
- Perfect Toys for Kids Learn to Walk or Ride
- Non-Toxic and BPA Free



HUR3T5



HUR3Z6



HUR3U7

What's in the Box:

- 3 in 1 Toddler Bike

Technical Specs:

- Construction Materials: Carbon Steel
- Recommended Age: 10-36 Months
- Weight Capacity: 80 lbs.
- Product Dimensions: 27.6" x 11.5" x 19.5" -inches



Questions? Issues?
We are here to help!
Email: cs@hurtleusa.com