

IMPORTANT:

Read and understand this entire manual before allowing child to use the HURTLE PRO STUNT SCOOTER!

SAFFTY WARNINGS:

AN IMPORTANT MESSAGE TO PARENTS

This manual contains important information.

For your child's safety, it is your responsibility to review this information with your child and make sure that your child understands all warnings, cautions, instructions and safety topics.

All children and preteens should ride with adult guidance at all times. Hurtle Pro Stunt Scooter recommends that you periodically review and reinforce the information in this manual with younger riders, and that you are required to inspect and maintain your child's scooter to ensure their safety

FAILURE TO USE COMMON SENSE AND HEED ALL WARNINGS **FURTHER INCREASES RISK OF SERIOUS INJURY, USE AT YOUR** OWN RISK AND WITH APPROPRIATE AND SERIOUS ATTENTION TO SAFE OPERATION. USE CAUTION.



ASSEMBLY INSTRUCTIONS:

- 1. Take the scooter out of the box, then lay it all out unassembled parts.
- 2. Insert the fork with the front wheel into the steering glass at the bottom of the boards forms. Tighten the nut fixing bolts.
- 3. Install the steering wheel with lock on the fork rod, then tighten everything fixing bolts.







OPERATION:

- 1. Before each scooter operation, check reliability of fastenings. Operation of the scooter with weakened fastenings can lead to bending of the structure and, as a result, accident will happen.
- 2. During assembly-disassembly of the scooter, be careful not to pinch your fingers with clamps.
- 3. If dirty, do not spray the scooter with water from a bucket or hose. Remove dirt from the scooter using a soft lazy tissue. Use of mild detergents is allowed. Do not use abrasive cleaners so as not to scratch the surface of the scooter.
- 4. To prevent corrosion and peeling of the paint, store the scooter in ventilated dry room away from sunlight.
- 5. In the event of bearing wear or damage, replace bearings yourself or in a specialist services.
- 6. In cases of detection of any defect or non-compliance parts, do not try to correct the defect, contact the seller.
- 7. Max loading is 100kgs.



PRECAUTIONARY MEASURES:

- 1. When using the scooter, it is highly recommended to wear a safety helmet, elbow pads and knee pads.
- 2. Do not ride the scooter on the roadway or in crowdy places, uneven areas and other dangerous places.
- 3. Do not ride on wet, slippery, or excessively dirty roads.
- 4. Do not operate the scooter at night and in conditions of poor visibility.
- 5. Only 1 person can ride a scooter at a time.
- 6. Children under 10 years old should ride a scooter under adult supervision. The scooter is not intended for children under 3 years old.
- 7. To control the speed, please use the rear brake of the scooter. The brake is an auxiliary device and can't stop the scooter instantly. Brake action is limited when driving on sloping tracks.
- 8. Do not attempt to make structural changes of scooter on yourself.
- 9. Avoid sharp bumps, drainage grates and sudden surface changes. Scooter may suddenly stop.
- 10. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking, and visibility.
- 11. Avoid excessive speed associated with downhill rides.
- 12. Adults must assist children in the initial adjustment procedures to unfold scooter, adjust handlebar and steering to height, and finally to fold scooter.
- 13. Obey all local traffic and scootering laws and regulations.
- 14. Watch out for pedestrians.
- 15. Check and secure all fasteners before every ride.
- 16. Replace worn or broken parts immediately.





Questions? Issues?

We are here to help!

Email: cs@hurtleusa.com