

FRONT

SIZE: 411(W) X 279(H)mm
COLOUR: BLACK

INSTRUCTION MANUAL

Waterproof Wireless Stereo Speaker With Microphone


Waterproof Wireless Stereo Speaker With Microphone



This product is waterproof and designed with quality stereo sound that will enrich your bath time, enjoy your favor music at anywhere at any time. Its Bluetooth compatible wireless system allows easy pairing with devices (such as tablets, notebooks, smartphones & PCs). Also has a built-in microphone to allow you to talk on the phone while you are in the shower.

Waterproof performance:
The waterproof level of this product complies with IP47 standards, is designed to ensure normal operation in water at a specified conditions.

Product Description:



Before using this unit:

Please ensure that the watertight cap of the DC line in plug is completely closed before using this unit. Damage can happen if water is allowed to seep into the unit from a loosely closed watertight cap. Water droplets that enter the speaker or microphone holes do not cause damage to unit. However, the product performance may temporarily decrease until the water droplets are dried. Problems may include unclear sound and microphone insensitivity. If such circumstances exist, please remove water droplets and dry the product.

Product Specifications:

Bluetooth version	Bluetooth V2.1 +EDR A2DP and AVRCP
Operating range (maximum)	32 feet (The transmission distance changes depending on the environment where the product is used.)
SNR:	≥80dB
Impedance:	4ohm
Power supply	4pcs x AA Battery (Alkaline batteries are recommended) 5V DC plug is optional
Current consumption:	500 mA (Max)
Continuous standby time: #	180 Hours
Continuous transmission time: #	8 hours
<p>#The actual continuous standby/transmission times may become shorter than those in the specifications depending on the environment or conditions for keeping/using the unit, etc.</p> <p>#Batteries are consumables. The battery service time gradually decreases after the charging and discharging cycles, even if the batteries are used properly.</p> <p>#The battery performance deteriorates quickly if the unit is kept under high temperature conditions. Please keep the unit in a cool, well-ventilated location, away from direct sunlight.</p>	
Operating Temperature:	90 °F to -40 °F
Operating humidity range:	20-80% (no condensation)
Product size:	8" (L) x 1.8" (W) x 3.5" (H)
Weight:	Approx. 10 oz.
Waterproof performance:	IP47
Number of devices that can be registered	8

Installing batteries:

- Turn to open the battery door according to the label indicator
- Please follow the polarity indicated inside of battery compartment.
- Put 4 AA batteries (Alkaline batteries are recommended).
- You can optionally power by 5V DC adapter (Please note that while operating by DC 5V adapter, do not use in wet place)
- When the battery power is depleted, a beeping alarm will sound, with the LED lamp blinking red. After a while, speaker will turn off.

Pairing the product with your device:

1. To turn on the product, hold **ON/OFF** for around 7 seconds, a signal will sound "BEEP-", keep pressing until red and blue light are flashing, and you will hear a "BIBI" sound, this means the unit is ready to be paired.
2. The first time your unit is paired, use your device to search for the product model "PBTW20".
3. When your device finds the product model, press to connect, your device will show if it is successfully connected or not.
4. If it is successfully connected, you can play music through the product.

Waterproof Bluetooth Stereo Wireless Shower Speaker System
& Hands Free Speaker-phone
PBTW20



www.PyleAudio.com



BACK

SIZE: 548.5(W) X 279(H)mm
COLOUR: BLACK

Waterproof Wireless Stereo Speaker With Microphone

Waterproof Wireless Stereo Speaker With Microphone

Waterproof Wireless Stereo Speaker With Microphone

Note:

- Terminate any connection between the product and any other device before starting the pairing procedure.
- The pairing procedure cannot be started while a Bluetooth connection is established between the product and a registered device. Terminate the connection and turn off the product.
- Noted that the pairing procedure cannot be started while the product is connected to a device via an AUX line in cable

Up to eight Bluetooth device can be registered:

When nine or more devices are registered, and you try to add a tenth the previously registered devices will be deleted starting from the oldest, to register new ones. A device that is registered twice is identified as one device.

Play music:

Press **vol+** to increase the volume. (when at maximum, you will hear 'Beep~' sound)

Press **vol-** to decrease the volume. (when at minimum, it will have 'Beep ~' sound)

Press **⏮** to restart the current track. Press twice to play previous track.

Press **⏭** to play next track.

Press **⏸** to pause/ play the track.

Handfree calling :

Part 1 pick up call:

1. When you have an incoming call, press **ON/OFF** to pick up the phone.
2. Press **vol+** to increase the speaker volume
3. Press **vol-** to decrease the speaker volume
4. After you finish the conversation, press **ON/OFF** to hang up.

**Note: To avoid/ reduce echo, please do not turn the speaker to maximum.

Part 2 make a call:

1. Hold **ON/OFF** for 2 seconds to redial the last number you dialed.
2. Some Smartphones have voice command, press **ON/OFF** once to enter voice command function with your Smartphone. For details, please refer your Smartphone's instruction. This function is different depending on your Smartphone's setting.
3. After you finish the conversation, press **ON/OFF** to hang up.

Part 3 pick up another incoming call:

1. While you are talking over the phone and receive another incoming call, press **ON/OFF** twice to pick up incoming call.
2. Press **ON/OFF** twice to switch to another party.
3. Press **ON/OFF** once to hang up the phone

Part 4 reject incoming call:

1. When you hear the ring of an incoming call, hold **⏸** to reject the call.
2. If you are listening to audio, press **⏸** once again to continue playing audio.

Initializing the registration history / resetting the hardware :

When unit is turned off, press **ON/OFF** & **vol+** together until you hear a tone and see a red light.

Using Aux Line in:

When stereo is turned off, directly connect line in cable with your audio device, then play and control the volume on your device. To save power, please ensure the speaker Bluetooth mode is turned off.

Please note: these keys **vol+ / vol- / ⏮ / ⏭ / ⏸** are not functional while playing via line-in cable.

**When the unit is connected to an audio device via an audio cable, please do not use the unit in a wet or damp environment, because the watertight cap cannot be closed to ensure waterproof performance.

Caution:

- Please take full precautions when setting the ringtone volume. When this product is paired with a mobile phone, a loud ringtone may startle you at large volumes, which in turn may result in an accident or a heart attack. Gradually increase the volume from minimum to louder to set it appropriately.
- Do not damage cables that are connected to this product. Fire and injury may result from damaged cables
- Never leave this product in a car. Leaving this product in a hot car for many hours will result in rupture of the built-in battery, sparking posing significant danger.
- Do not leave this product under high temperature conditions. This product is a precision electronic device. Avoid using/ keeping this product in a location that is subject to high temperature, high humidity or direct sunlight for many hours. When subject to significant temperature changes in the environment, this product may malfunction due to condensation inside the product.
- Do not touch the metal parts of this product such as the power supply connectors and the charging cable's connector terminals. Static electricity or fouling may cause a malfunction or electric shock.

- Do not disassemble this product. Do not repair, modify or disassemble this product on your own, unless operational instructions to the contrary are given in this user's manual, Electric shock, fire, or burns may result.
- Make sure to close the watertight cap when using this product in a wet or damp environment. Make sure to remove any dust, hair, etc., that is present between the watertight cap and the main unit.
- Follow the user's manual instructions of devices (ex. iPhones and mobile phones) to be connected to this product. This product can be wirelessly connected to iPhones, mobile phones, etc. The setting procedures and precautions are different depending on the devices to be connected to this product. Carefully read the user's manual for these devices and observe any precautions.
- Do not use/keep this product in a wet or damp environment for a long time if you do not use it. Any liquid entering this product may result in troubles, fire, or electric shock.
- Do not keep this product within reach of small children. Unexpected accidents (ex. accidental ingestion) may result.
- This product is a precision electronic device. Avoid using/keeping this product in an environment that is subject to impact/vibration, strong magnetic forces, static electricity, etc.

FCC Requirement:

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

4. Reorient or relocate the receiving antenna.
5. Increase the separation between the equipment and receiver.
6. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
7. Consult the dealer or an experienced radio/TV technician for help.



www.PyleAudio.com