# **PyleUSA.com**

Questions? Comments? We are here to help! Phone: (1) 718-535-1800 Email: support@pyleusa.com

## **PyleUSA.com**



### *PPHP6235B* Dual 6.5" Multi-Purpose Speaker System

Rechargeable Speaker with Remote Control, Digital Display, USB/Micro SD/FM/BT/Aux Input (2x150 Watt)



#### PLEASE READ THIS MANUAL CAREFULLY BEFORE OPERATION



#### **CAUTION:** TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER [OR BACK]

THIS PRODUCT MUST BE EARTHED

#### NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

#### Features:

- LED Screen
- Touch Button to control the Echo, Light, Bass, and EQ
- Instantly Stream Music from your iPhone, Android, MP3 Player, Tablet, PC, etc
- High Performance, High-Quality Speaker
- 60 Watts of Peak Music Power Output
- Includes Multi-color DJ LED Light
- USB/Micro SD Port/BT/FM/Aux Input
- Digital Display
- ON/OFF Switch to Control LED Lights
- Built-in Rechargeable Battery
- Master Volume, Mic Volume,
- (2) 1/4" -inch (6.35mm) Microphone/ Guitar Instrument Inputs
- Aux (3.5mm) Input Jack
- Convenient Integrated Carry Handle
- Rugged & Durable Molded Cabinet Design
- Perfect for Karaoke, Parties, Conferences, Indoors/Outdoors, and More

#### Wireless BT Streaming:

- Instantly Stream Music from Your BT Devices
- Works with All Your Favorite BT Devices (iPhone, Android, Smartphone, iPad, Tablet, PC, etc.)

- Wireless BT Version: 5.0
- Wireless BT Range: >10m
- Wireless BT Network Name: Pyle

#### What's in the Box:

- Speaker box
- Remote Control
- Manual

#### **Tweeter Specs:**

- Size: 1.5" -inch
- Material: Mylar
- Sensitivity: 94dB/1m. w
- Voice Coil: Piezoelectric
- Frequency Response: 2k-16KHZ

#### Subwoofer Specs:

- Size: 6.5" -inch
- Material: Stamped Steel Basket
- Impendence: 4 Ohm
- Magnet: 10 oz.
- Voice Coil: 25mm, 1" -inch
- Sensitivity: 88dB
- Frequency Response: 63Hz-7.5kHz


#### **Technical Specs:**

- Max Power Output: 300W (2x150 Watt)
- Amplifier Class D
- Lithium Battery 11.1V / 3600mAh
- Battery Life: 3-4 hours
- LF: 2 x 6.5" -inches
- Impendence: 4 Ohm
- Digital Audio File Compatibility: MP3, WMA, WAV
- Maximum SD/USB Flash Memory Support: 64GB
- Power: 100-240V 50/60HZ
- Dimensions (L x W x H): 21.95" x 9.56" x 9.9" -inches

#### **OPERATION**

- 1. Prior to switching ON, turn volume down to minimum.
- **2.** Connect the audio source to the appropriate input socket.
- 3. Connect to the mains supply.
- **4.** Set the volume with the applicable control.

#### **Controls and Connections**



- 1. MIC 1 Input
- 2. MIC 2 Input
- 3. Line Input
- 4. USB Input
- 5. Micro SD Card Input
- 6. Main power switch
- 7. LED Light switch
- 8. Mic input volume control
- 9. Master volume control
- 10. ECHO for mic in port
- 21. EQ mode 11.E CHO + for mic inport
  - 22. LED Display screen

12. Wireless BT mode

13. LED Color Control

16. BASS Control

17. Previous Song

18. Next Song

20. Play/Pause

14. MIC Input to your USB driver or MicroSD card

15. MODE: USB/MicroSD/BT/FM/LINE

19. Repeat one/repeat all/Random

#### **INSTRUCTIONS**

- Do not overload the box to avoid damage to the speakers.
- Do not place an open fire (candle, etc.) on top or next to the box FIRE HAZARD
- Only connect to an earthed mains outlet of AC 100-240V-50/60Hz.
- For indoor use only. If the box is used outdoors, you need to make sure that no humidity can enter the box.
- When not in use, unplug the unit from the mains.
- Unplug the unit from the mains prior to checking or replacing the fuse.
- Make sure that the box is placed on a stable, strong surface.
- The boxes can be hung. Use only strong and approved mounting material. During the mounting, make sure that nobody is standing below the mounting area.
- Do not place liquids on the box and protect it against humidity. Humidity can shorten the life time considerably.
- Only use suitable means of transportation if you want to move the box -**BEWARE OF YOUR BACK!!**
- Always unplug the unit during a thunderstorm or when it is not in use.
- If the unit has not been used for a long period of time, condensation can occur inside the housing. Please let the unit reach room temperature prior to use.
- Never try to repair the unit yourself.

It does not contain any user serviceable parts.

- Run the mains lead in such a way that nobody can fall over it and nothing can be put in it.
- Set the unit to the lowest volume prior to switching it on.
- Keep the unit out of the reach of children.

