

SereneLife

by **PYLE**



SLELT367

36" Kids Trampoline

USER MANUAL

SAFETY INSTRUCTIONS

1. Misuse and abuse of this trampoline is dangerous and can cause serious injuries.
2. All purchasers and all persons using the Trampoline must become familiar with the manufacturer's recommendations for proper assembly, use and care of the Fitness Trampoline.
3. The owner and supervisors of the trampoline are responsible to make all users aware of the Safety Instructions.
4. Place the Trampoline on a level surface before use.
5. Inspect your Trampoline before each use. Make sure the safety pad is in place. Replace any worn, defective, or missing parts.
6. Make sure to provide adequate clearance for ceilings, ceiling lights, ceiling fans, wires and tree limbs. Failure to provide adequate head clearance can result in head or neck injury.
7. Place the Trampoline away from walls, structures, fences, play areas, furniture and other exercise equipment. Maintain a clear space on all sides of the trampoline. Remove all obstructions from beneath the Trampoline.
8. Good traction is very important using the Trampoline. Bare feet are acceptable but we recommend good footwear with rubber non-skid soles.
9. The Trampoline should be used by only one person at a time.
10. Do not attempt any gymnastic or acrobatic maneuvers on the Trampoline.
11. Always store the Trampoline indoors in a dry place and make sure that the surface of the bed is always dry before using.
12. Secure the Trampoline against unauthorized and unsupervised use. The Trampoline is for consumer use only. Public or semipublic use is not allowed.
13. The maximum user weight is 150 LBS.

WARNING: Recommended for children 3+ years.

Do not leave child unattended while in use. Use only under adult supervision.






WARNING
For 3+ years of age
150 lbs weight limit
Proper adult assembly required

READ AND FOLLOW THE SAFETY INSTRUCTIONS.
FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY.

Parts List

Nr.	Parts Description	Quantity
1	Frame	1
2	Jumping Mat	1
3	Elastic Band	28
4	Protective Padding	1
5	Leg	6
6	Covering Cap	6
7	Handrail Tube	3
8	Kitbag	1




Assembly Instruction



WARNING

1. Keep children away from the trampoline during assembly.
2. Keep fingers away from the ends of the rails in the hinge area when unfolding the trampoline.
The RAILS will try to spring back to the folded position if they are released before the snap into place.
Serious injury can occur if fingers are caught between the ends of the RAILS.
3. Assembly and disassembly must be carried out by two people to minimise the risk of injury.



STEP 1

Lay the folding trampoline on the floor in its still folded position. Push out the ends so the trampoline forms a semi-circle.





STEP 2

Remove the bracket pin from both ends of the trampoline, and place them to the side.


**STEP 3**

Both persons press rails C and D, and using steady pressure, with hands open and fingers extended, use palm of hands to push rails A and B down until they touch the ground. Make sure that all joints are locked into place.





STEP 4

Insert the PIN back to the bracket to prevent rails from snapping together when you reach the flat position



STEP 5

Remove the covering cap on the threaded connector, and slide the protective padding (#4) over the unfolded frame. Make sure the holes on the underside of the protective padding are positioned exactly over the threaded connector for the feet. Make sure handle brackets are visible.




WARNING:

- Make sure handle brackets are visible
- The protective pad must be securely attached to the frame before using the trampoline.
- Must be properly positioned.

STEP 6


Turn the frame upside down. Screw the six feet on to the threaded connectors on the underside of the frame. Turn the trampoline over and place it on its feet.

**STEP 7**

Insert the two handle support tube (#A) into trampoline base handle brackets.

Attention: Bends of handle support face up and toward center of trampoline.

Make sure holes aligned. Using the washer (#C) and screw (#D), secure the handle support to the trampoline base by wrench provided. Then secure the top handle to the handle support by using the washer (#C) and screw (#D)

**CARE AND MAINTENANCE**

Inspect the trampoline before each use and replace any worn, defective or missing parts. The following conditions could represent potential hazards:

1. Missing, improperly positioned, or insecurely attached frame padding.
2. Punctures, frays, tears, or holes in the bed, or frame padding.
3. Deterioration in the stitching or fabric of the bed or frame padding.
4. A bent or broken frame.
5. A sagging bed.
6. Sharp protrusions on the frame of suspension system.

⚠️ WARNING ⚠️
IMPORTANT – PLEASE READ!
WARNING – GENERAL SAFETY ADVICE

- Please read the instructions before use and retain for future reference.
- Ensure the trampoline has been assembled correctly, as per the instructions in the manual.
- It is essential that the intended site for this trampoline is completely flat and level.
If the ground is un-level this will cause movement in the frame and could cause stress on the joined sections.
- **DO NOT** exceed the recommended **MAXIMUM WEIGHT** limit of **150 LBS**.
- **DO NOT** allow more than one person on the trampoline at a time.
- **DO NOT** wear glasses or helmets when using the trampoline.
- **DO NOT** fall or bounce on your knees, this can cause injury.
- **DO NOT** use the trampoline in wet or windy conditions.
- **DO NOT** somersault – this can cause serious injury.
- **DO NOT** allow other persons to go under, sit, stand or lie on the frame pads whilst the trampoline is in use.
- **DO NOT** use the trampoline when under the influence of alcohol, drugs or medication which may impair the jumper's judgement.
- **ALWAYS** wear socks when using the trampoline.
- **ALWAYS** remove jewellery before using the trampoline.
- **ALWAYS** jump in the middle of the trampoline bed.
- **ALWAYS** follow the safety warnings stated with your trampoline instructions in conjunction with using enclosure.
- **NEVER** wear footwear (e.g. shoes) when using the trampoline.
- Children **MUST NEVER** use the trampoline unless supervised by a responsible adult with knowledge of trampoline use.
- Before trampolining, inspect and replace any worn, defective or missing parts.
- Ensure the trampoline is on level ground with a minimum of 2.5M clear space around the sides, 8M clear height space above and that nothing is under the trampoline.
- Mount and dismount the trampoline with care as injury may result.
- Please read and refer to other warnings and use information in the instructions before use.

Please retain this information for future reference.



VISIT US ONLINE:

Have a question?

Need service or repair?

Want to leave a comment?

[PyleUSA.com/ContactUs](https://www.pyleusa.com/contact-us)

PYLE