SereneLife

SereneLife



SLPUMP25

Electric Air Pump Compressor/Air Inflator

Perfect Inflator Pumps for SUP, Outdoor Camping, Inflatable Cushions, Air Mattress Beds, Boats, Swimming Ring

USER MANUAL

Questions? Issues?

We are here to help! Phone: (1) 718-535-1800 Email: support@pyleusa.com

READ THIS USER MANUAL CAREFULLY BEFORE USING THIS EQUIPMENT.

User Instructions must always be available to the user and are not to be removed except by the user of this equipment.

CATALOGUE

I. Product Introduction		2
II. List of Accessories		2
III. Details of Accessories		2
IV. Safety Instructions		4
V. Precautions		5
VI. Charging		5
VII. Inflation Operation		6
VIII. Fault Handling		7
IX. Maintenance and Storag	ge	8
X. Features and Technical S	pecs	9

I. PRODUCT INTRODUCTION


SLPUMP25 is an intelligent DC electric pump with the preset pressure LCD screen, which can be used for inflatable tent, SUP, etc. Thanks to the intelligent pressure system, for example, if a pressure value is preset, when the pressure reaches the preset pressure value, the pump will automatically stop inflating.

II. LIST OF ACCESSORIES

Please make sure that the following accessories are in the box before using it, if any missing, please contact with the local supplier.

Air pump	Hose/Type-C USB cable	User Manual

III. DETAILS OF ACCESSORIES



- 1 Inflation inlet
- (2) Pressure value LCD screen
- (3) Pressure unit toggle button
- (4) Pressurizing button
- (5) Decompressing button
- 6 On/off button
- (7) Switch
- (8) Air tap
- 9 Hose
- (10) Flexible conduit adaptor
- (11) Air inlet
- 12) Type-C USB cable
- (13) Charging indicator light
- 14) Type-C power input interface

IV. SAFETY INSTRUCTIONS

- **Warning:** In order to reduce the risk of injury, please keep children away from it. Always supervise children and incapacitated person contacting or using this air pump.
- Warning: Children shall be kept far away from this product and wire.
- **Warning:** This product is not applicable for the person with declining physical strength, sensory ability or mental capacity, the person lack of skill and limited in mental development, unless they are under the protection of their guardians, supervised and directed at the same time.
- **Warning:** Before moving, maintaining, repairing or adjusting this product, please first pull out the DC plug from the socket.
- **Warning:** Please do not bury the wire in the soil, and it shall be place in the safe zone where it won't be damaged by mower or other equipment.
- **Warning:** If the power wire is damaged, the power wire must be changed by the manufacturer or its service agent or the similar authorized personnel, in case of any risk.
- **Warning:** If you are standing in a place with water or your hands are wet, please don't plug or pull the DC plug.
- **Warning:** Before inflating, please pay attention to check the maximum bearable pressure of the inflatable product, because the air bag may be damaged upon exceeding the maximum bearable pressure.
- **Warning:** Do not place the product in a hot or humid environment for fear of short circuit of the internal circuit resulting in serious damages to the product.
- **Warning:** Do not put this product in fire for fear of explosion, battery leakage and other dangers.
- **Warning:** Do not use or store this product in an environment where the temperature is too low or too high, which may result in automatic protection of the product and cut off the charging of the product.
- **Warning:** Please use this product in a relatively safe environment and keep the product off flammable and combustible liquid, gas or explosives.
- Warning: Please verify that the adapter matches this product before charging; an unmatched adapter may cause damage to this product or cause danger due to over load.
- **Warning:** When the product is not used, please put it in a ventilated and dry place and avoid contacting with metal materials to cause short circuit. Please pay attention to heat dissipation and ventilation during use to avoid any danger caused by over temperature.

- **Warning:** Do not dismantle the device randomly, since this product is not equipped with any parts that can be dismounted/maintained by users.
- **Warning:** Please do not cover or shield the product with paper or other objects for fear of affecting heat dissipation and cooling.

V. PRECAUTIONS

- When charging with Type-C USB 5V 2A/12V, the product can not be started during charging.
- Don't block the air inlet (11) at the bottom of the air pump, and guarantee air inlet (11) to be always unblocked.
- Observe the local waste treatment provisions, and it is not allowed to throw the air pump away randomly.
- Don't use this product when the hose is damaged, and please change the hose immediately.
- Don't pull out the hose when inflating, because that the high pressure may hurt the physical body.
- Don't make the air pump work for more than 20 minutes, because that motor overheating may cause internal damage; and the air pump shall be fully cooled for 30 minutes after continuously working up to 20 minutes.
- Please don't use this air pump if any part is damaged, and please contact with the professional personnel to repair it.
- This product shall not be exposed to the rain or immersed in water. In order to prevent risk, the inflation inlet shall not be forward to face or body.
- Please don't not leave while inflating.

VI. CHARGING

- Please use the Type-C USB cable provided with this product for charging, the charging voltage is 5V 2A, and the charging time is about 8 hours. If a quick charger of QC2.0 or higher is chosen for charging, the charging time is about 4 hours. As shown in Figure 1
- When only one indicator is on, it is recommended to charge the product in time. The indicators will flash during charging, and all the indicators will be on when the product is fully charged.
- Make sure the battery is fully discharged before the first charge.




Figure 1

- The battery should be recharged immediately after it is discharged. Please do not lay the pump aside without power for a long time.
- The battery must be removed from the appliance before it is scrapped:
 - the appliance must be disconnected from the supply mains when removing the battery;
 - the battery is to be disposed of safely.

VII. INFLATION OPERATION

- Use the pump directly in which the battery has been fully charged.
- Connect the Flexible adaptor (10) of the hose with the air pump inflation inlet (1), and twist clockwise to tighten it, as Figure 2.
- Install the other end (8) of the hose into the nozzle matching the air bag and turn clockwise to tighten it; then insert the inflation valve of air bag, and turn clockwise to fixed firmly, as shown in Figure 3.
- Turn on the power switch. (the symbol "-" on the switch means "ON", "• means "OFF")
- Press the pressure unit toggle button (PSJBAR) to select the unit you need.
- Press the pressurizing button or decompressing button to set the pressure value you need, with the range of the pressure value from 0 to 16PSI, (1PSI=0.0689BAR)
- After finishing the above steps, press the power switch button to start to inflate. During the inflating process, you can press the pressurizing button to increase or reduce the pressure value, press the pressure unit toggle button to switch the unit, and press the On/Off button to stop.




Figure 2




Figure 3

- When the pressure reaches the set value, the air pump will stop working automatically.
- When not in use, turn off the power switch " -", remove the hose from the air pump and air bag and store the product properly. (the symbol "-" on the switch means "ON", "O" means "OFF")
- **Notice:** The factory set pressure value of the air pump is 10PSI (10PSI=0.689BAR), and at the time of the secondary use, the set pressure value for the last time use will be displayed by default.
- **Notice:** After powered on, if there is no operation within 2 minutes, the air pump will enter standby mode, and the machine can be initiated by pressing the power switch button .

VIII. FAULT HANDLING

Fault	Inspection	Solution
The air pump pump won't start normally.	 Check if the switch "e" is turned on and the battery is fully charged. Overheating or overload causes motor stop. 	 Turn on the power switch and charge it in time Cool off the motor and restart it. If the problem cannot be solved, please contact local agents or the similar authorized personnel.
Slow or abnormal inflation.	 Check whether the hose is blocked or cracked. The joint between the hose and air pump or air bag is not installed properly. 	 Change the hose or make it unblocked, and check whether the hose is cracked. Reinstall the hose. If the problem cannot be solved, please contact with the manufacturer or its service agent or the similar authorized personnel.

IX. MAINTENANCE AND STORAGE

- After using, or if you want to move, maintain or adjust the product, please first pull out the DC plug from the socket.
- When it is idle, it shall be properly stored after being fully cooled.
- It shall not be exposed to the rain or immersed in water.
- Please store it in the dry and ventilated place.

Suggestions:

The warranty period of this product is one year, and it is suggested to use the original accessories. For any fault not caused by using the original accessories, it shall be out of the warranty scope.



X. FEATURES AND TECHNICAL SPECS

Features:

- Intelligent Electric Air Pump for Stand Up Paddle-boards & Water Sports Inflatable Pool, etc.
- Compact and Portable Design
- Simple and Hassle-free Operation
- Digital LCD Display & Button Controls
- Adjustable PSI (Pounds per Square Inch) Air Pressure Settings
- Built-in Rechargeable Lithium Battery
- Powerful Inflator for Both Indoor and Outdoor Use

What's in the Box:

- Air Pump
- Detachable Air Hose
- Type C USB Cable

Technical Specs:

- Power Output: 110 Watt
- USB Power: DC 5V 2A
- Adjustable Air Pressure: 0-16 PSI
- Air Hose Length: 3.3' ft.
- USB Cable Length: 3.3' ft.
- Charging Time: 8 Hours
- Battery Type: 18650 Lithium Battery, 4000 mAh
- Product Dimension (L x W x H): 9.1" x 5.5" x 4.7" -inches