



SLSFE26PS



SLSFE28PS

PISTOL SAFE

USER MANUAL




Figure 1. Pistol Safe




Figure 2. Keypad




Figure 3 & 4. Battery compartment located in locking assembly

Opening Safe

The safe can be opened in two ways- using either the included key, or by entering the correct code into the keypad.

Perform the following steps for the initial setup of your safe. At any time, the override key can be used to open the safe door (**NEVER STORE OVERRIDE KEY IN SAFE**)

To prepare safe for use:

1. Use override key to open door.
2. Install batteries
3. Enter default factory code: 1-2-3

Note: If code was entered correctly, green light will flash for two seconds and the spring-loaded door will open swiftly.

Note: If code was entered incorrectly, red light on keypad will flash for three seconds.

Adding/Changing Batteries

1. Place safe on its side, and locate the battery compartment on locking assembly shown in figure 3.
 2. Remove battery compartment cover, install 4*AA batteries into battery compartment, and re-install battery compartment cover.
 3. Position safe upright. Push reset button.
- NOTE:** If batteries are installed properly, green light on keypad will illuminate, followed by a red light.
4. Close safe door.

Changing Digital Lock Safe

After the successful completion of each step, the safe will beep the indicated number of times and flash the indicated color.

To change digital lock code:

1. Open door using current code or override key.
2. Press and hold reset button (*see Figure 4*)
On bottom of locking assembly for three seconds. Two beeps sound and green light flashes.
3. Enter new 3-to 8-digital code. Codes less than eight digits long require you to push reset button to finalize the input. Otherwise, once the eighth digit is pressed the code will automatically be accepted. A yellow light will flash if the code is changed successfully.

NOTE: If five beeps sound and red light flashes, it means

the procedure was unsuccessful. Repeat Steps 2-3.

4. Re-enter a new 3- to 8- digit code. Codes less than eight digits long require you to push reset button to finalize input. Otherwise, once the eighth digit is pressed the code will automatically be accepted. Green light will flash if code is accepted.

- If five beeps sound and red light flashes, procedure was unsuccessful, repeat Steps 2-4.

5. Close door and test new code.

NOTICE

Keep these instructions with included combination and override keys in a separate secure location from safe. Misplacing override keys and forgetting the combination will render the safe unusable.

Invalid Entry Wait Period

6. If you enter an invalid code three consecutive times, the digital lock begins a two-minute wait period. At the end of wait period the safe can be accessed normally.

7. While in wait period

- The digital lock will flash all three lights together if code entry attempt is made.
- The digital keypad will not accept input.
- Removal of the battery stops the countdown but will not reset the wait period.
- Override key can be used to access safe.

Silent Mode

This safe features a silent mode that mutes the beeps heard when buttons are pushed on the keypad. The indicator lights will still flash in silent mode.

To enable silent mode:

1. Push and hold button 1 on the keypad until all three lights illuminate.
2. Enter code to test that beeps are inaudible.

To disable silent mode:

1. Push and hold button 1 on the keypad until all three light illuminate.
2. Enter code to test that beeps are audible.




Figure 6. Bolting to wood floors




Figure 5. Anchoring to concrete floors.

Maintenance

Clean the surface of the safe with a slightly damp cloth.

If the hinges develop a squeak, apply one or two drops of light machine oil to hinge contact points.


If the digital lock's yellow light flashed, this indicates the AA batteries are low, please replace the batteries immediately. Otherwise, replace once per year.

Anchoring Your Safe

Anchoring the safe to an immovable surface makes theft of the entire safe extremely difficult. The safe can be anchored to any surface, but wood and concrete are the most common.

Before anchoring the safe, the shelf and foam padding must be removed to expose the anchoring holes in the bottom of the safe. Mark through the mounting holes before drilling.

The following are the most common scenarios for mounting your safe. However, since the safe can be mounted to numerous surfaces, use discretion to determine the best mounting method.



Anchoring to Concrete Floors

Lag shield anchors are generally recommended because they mount flush with the floor and allow the safe to be bolted down with a lag screw and flat washer. Ensuring that the lag shield anchors are flush with the floor aids in the ease of movement at a later time.

Installation of lag shield anchors requires you to drill holes into the concrete. Drilling into concrete properly requires a hammer drill with an appropriate-sized concrete drill bit.

To ensure strong and successful anchoring to concrete:

- Drill holes in one pass and avoid raising the bit up and down to clear the dust, which may cause the holes to become slightly over-sized.
- Drill holes 1/2"-1" deeper than the length of the lag shield to allow room for the bottom of the screw and any remaining dust.
- Vacuum dust from holes before installing lag shields.

Bolting to Wood Floors

Lag screws and flat washers are typically used to bolt safes to wood floors (or floors with a wood sub-floor).

Installation of lag screws works best if holes are pre-drilled to accommodate the lag screws. A standard hand-held power drill with the appropriate-sized wood drill bit is required to complete the job.

To ensure strong and successful anchoring to wood:

- Pre-drill holes at the correct size for the lag screws. The correct pre-drill size is always smaller than the lag screw size. (For example, a 7/32" bit is used to pre-drill holes for a 3/8" lag screw)
- Use at least a 2" long lag screw.
- For additional strength, fasten at least two of the screws into floor joists.

SereneLife™